| Original | | Rechange | |
|---|---|---|---|
| MAIN P ON | Main Power On | | Power |
| POWER OFF | Main Power Off | SHIFT + | Shift + Power |
| SOURCE POWER | Source Power | OK | OK |
| SOURCE POWER | Power Source | SHIFT + OK | Shift + OK |
| PHONO | Phono | SHIFT + TV 1 | Shift + 1 |
| CD | CD | SHIFT + CD-STB 3 | Shift + 3 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| CD-R | CD-R | SHIFT + USB 8 | Shift + 8 |
| AUX | AUX | SHIFT + AUX-HDD 7 | Shift + 7 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TAPE | Tape | SHIFT + TAPE 5 | Shift + 5 |
| MD | MD | SHIFT + VIDEO 4 | Shift + 4 |
| 1 | 1 DVD | TV 1 | 1 |
| 2 | 2 DVD | DVD 2 | 2 |
| 3 | 3 DVD | CD-STB 3 | 3 |
| A F/P | A / F/P DVD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 4 | 4 DVD | VIDEO 4 | 4 |

| Original | | Rechange | |
|---|---|---|---|
| 5 | 5 DVD | TAPE 5 | 5 |
| 6 | 6 DVD | TUNER 6 | 6 |
| B-/-- | B/--/-- DVD | Prime Video RANDOM | Blue / Prime Video / Random |
| 7 | 7 DVD | AUX-HDD 7 | 7 |
| 8 | 8 DVD | USB 8 | 8 |
| 9 | 9 DVD | BLUETOOTH 9 | 9 |
| - | - DVD | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 DVD | HDMI-SAT 0 | 0 |
| + | + DVD | PC FAV MARKER | Fav / Marker / PC |
| 1-MODE TEXT | 1 Mode/Text | NETFLIX SEARCH | Red / Netflix / Search |
| 2-MODE TIME | 2 Mode/Time | APP REPEAT | Green / APP / Repeat |
| I<< | I<< DVD | PRESET- I<< | I<< / Preset- |
| ▶ | Play DVD | SLOW ▶ | Play / Slow |
| >>I | >>I DVD | PRESET+ >>I | >>I / Preset+ |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| << | << DVD | TUNE- << | << / Tune- |
| ■ | Stop DVD | HOLD ■ | Stop / Hold |

| Original | | Rechange | | Original | | Rechange |
|---|---|---|---|---|---|---|
| | >> DVD | | >> / Tune+ | | | |
| VOLUME | Volume Up | VOL | Vol + | | | |
| | Pause DVD | STEP-FREEZE | Pause / Step / Freeze | | | |
| OPEN/ CLOSE | Open/Close | SURROUND | Eject / Surround | | | |
| VOLUME | Volume Down | VOL | Vol - | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |
| | | | | | | |

| Original | | Rechange | |
|---|---|---|---|
| MAIN POWER ON | Main Power On | Power | |
| POWER OFF | Main Power Off | SHIFT + | Shift + Power |
| SOURCE POWER | Source Power | OK | OK |
| PHONO | Phono | SHIFT + TV 1 | Shift + 1 |
| CD | CD | SHIFT + CD-STB 3 | Shift + 3 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| CD-R | CD-R | SHIFT + USB 8 | Shift + 8 |
| AUX | AUX | SHIFT + AUX-HDD 7 | Shift + 7 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TAPE | Tape | SHIFT + TAPE 5 | Shift + 5 |
| MD | MD | SHIFT + VIDEO 4 | Shift + 4 |
| 1 | 1 Tune | TV 1 | 1 |
| 2 | 2 Tune | DVD 2 | 2 |
| 3 | 3 Tune | CD-STB 3 | 3 |
| A F/P | A / F/P Tune | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 4 | 4 Tune | VIDEO 4 | 4 |
| 5 | 5 Tune | TAPE 5 | 5 |

| Original | | Rechange | |
|---|---|---|---|
| 6 | 6 Tune | TUNER 6 | 6 |
| B/-/-- | B/-/-- Tune | Prime Video RANDOM | Blue / Prime Video / Random |
| 7 | 7 Tune | AUX-HDD 7 | 7 |
| 8 | 8 Tune | USB 8 | 8 |
| 9 | 9 Tune | BLUETOOTH 9 | 9 |
| MODE | Mode Tune | LIST SMART | Smart / List |
| - | - Tune | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 Tune | HDMI-SAT 0 | 0 |
| + | + Tune | PC FAV MARKER | Fav / Marker / PC |
| MEMO | Memo Tune | MEDIA DISPLAY | Display / Media |
| SCROLL | Scroll Tune | ANGLE INFO | Info / Angle |
| CANCEL | Cancel Tune | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| 1-MODE TEXT | 1 Mode/Text Tune | NETFLIX SEARCH | Red / Netflix / Search |
| 2-MODE TIME | 2 Mode/Time | APP REPEAT | Green / APP / Repeat |
| I<< | I<< Tune | PRESET- I<< | I<< / Preset- |
| >>I | >>I Tune | PRESET+ >>I | >>I / Preset+ |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |

| Original | | Rechange | |
|---|---|---|---|
| | << Tune | TUNE- | << / Tune- |
| | >> Tune | TUNE+ | >> / Tune+ |
| VOLUME | Volume Up | VOL + | Vol + |
| VOLUME | Volume Down | VOL - | Vol - |
| SOURCE POWER | Source Power | SHIFT + OK | Shift + OK |
| | + Tape | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| | - Tape | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| CANCEL | Cancel Tape | SHIFT + CLEAR EXIT CANCEL | Shift + Exit / Cancel / Clear |
| 1 -M TEXT | 1 Mode/Text Tape | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| DE-2 TIME | 2 Mode/Time | SHIFT + APP REPEAT | Shift + Green / APP / |
| MEMO | Memo Tape | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| B -/-- | B/-/-- Tape | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| A F/P | A / F/P Tape | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| | Play Tape | SHIFT + SLOW | Shift + Play / |
| | I << Tape | SHIFT + PRESET- | Shift + I<< / Preset- |
| | >>I Tape | SHIFT + PRESET+ | Shift + >>I / Preset+ |
| | << Tape | SHIFT + TUNE- | Shift + << / Tune- |

| Original | | Rechange | |
|---|---|---|---|
| | Stop Tape | SHIFT + HOLD | Shift + Stop / |
| | >> Tape | SHIFT + TUNE+ | Shift + >> / |
| | Pause Tape | SHIFT + STEP-FREEZE | Shift + Pause / Step / |
| OPEN/ CLOSE | Open/Close | SHIFT + SURROUND | Shift + Eject / Surround |
| | <> Tape | SLOW | Play / Slow |
| MODE | Mode Tape | SHIFT + LIST SMART | Shift + Smart / List |

| Original | | Rechange | |
|---|---|---|---|
| MAIN POWER ON | Main Power On | | Power |
| POWER OFF | Main Power Off | SHIFT + | Shift + Power |
| SOURCE POWER | Source Power | OK | OK |
| PHONO | Phono | SHIFT + TV 1 | Shift + 1 |
| CD | CD | SHIFT + CD-STB 3 | Shift + 3 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| CD-R | CD-R | SHIFT + USB 8 | Shift + 8 |
| AUX | AUX | SHIFT + AUX-HDD 7 | Shift + 7 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TAPE | Tape | SHIFT + TAPE 5 | Shift + 5 |
| MD | MD | SHIFT + VIDEO 4 | Shift + 4 |
| 1 | 1 CD-R | TV 1 | 1 |
| 2 | 2 CD-R | DVD 2 | 2 |
| 3 | 3 CD-R | CD-STB 3 | 3 |
| 4 | 4 CD-R | VIDEO 4 | 4 |
| 5 | 5 CD-R | TAPE 5 | 5 |
| 6 | 6 CD-R | TUNER 6 | 6 |

| Original | | Rechange | |
|---|---|---|---|
| 7 | 7 CD-R | AUX-HDD 7 | 7 |
| 8 | 8 CD-R | USB 8 | 8 |
| 9 | 9 CD-R | BLUETOOTH 9 | 9 |
| MODE | Mode CD-R | LIST SMART | Smart / List |
| – | - CD-R | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 CD-R | HDMI-SAT 0 | 0 |
| + | + CD-R | PC FAV MARKER | Fav / Marker / PC |
| MEMO | Memo CD-R | MEDIA DISPLAY | Display / Media |
| SCROLL | Scroll CD-R | ANGLE INFO | Info / Angle |
| CANCEL | Cancel CD-R | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| TEXT | 1 Mode/Text CD-R | NETFLIX SEARCH | Red / Netflix / Search |
| TIME | 2 Mode/Time | APP REPEAT | Green / APP / Repeat |
| ⏮ | I<< CD-R | PRESET- ⏮ | I<< / Preset- |
| ▶ | Play CD-R | SLOW ▶ | Play / Slow |
| ⏭ | >>I CD-R | PRESET+ ⏭ | >>I / Preset+ |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| ◀◀ | << CD-R | TUNE- ◀◀ | << / Tune- |

| Original | | Rechange | |
|---|---|---|---|
| | Stop CD-R | HOLD | Stop / Hold |
| | >> CD-R | TUNE+ | >> / Tune+ |
| VOLUME | Volume Up | VOL + | Vol + |
| | Pause CD-R | STEP-FREEZE | Pause / Step / Freeze |
| OPEN/ CLOSE | Open/Close | SURROUND | Eject / Surround |
| VOLUME | Volume Down | VOL - | Vol - |
| SOURCE POWER | Source Power | SHIFT + OK | Shift + OK |
| + | + MD | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| - | - MD | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| CANCEL | Cancel MD | SHIFT + CLEAR EXIT CANCEL | Shift + Exit / Cancel / Clear |
| 1 -M TEXT | 1 Mode/Text MD | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| DE-2 TIME | 2 Mode/Time | SHIFT + APP REPEAT | Shift + Green / APP / |
| | Play MD | SHIFT + SLOW | Shift + Play / |
| | I<< MD | SHIFT + PRESET- | Shift + I<< / Preset- |
| | >>I MD | SHIFT + PRESET+ | Shift + >>I / Preset+ |
| | >> MD | SHIFT + TUNE+ | Shift + >> / |
| | << MD | SHIFT + TUNE- | Shift + << / Tune- |

| Original | | Rechange | |
|---|---|---|---|
| | Stop MD | SHIFT + HOLD | Shift + Stop / |
| | Pause MD | SHIFT + STEP-FREEZE | Shift + Pause / Step / |
| OPEN/ CLOSE | Open/Close MD | SHIFT + SURROUND | Shift + Eject / Surround |
| MEMO | Memo MD | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| MODE | Mode MD | SHIFT + LIST SMART | Shift + Smart / List |
| B -/-- | B/-/-- MD | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| A F/P | A / F/P MD | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |

| Original | | Rechange | |
|---|---|---|---|
| MAIN POWER ON | Main Power On | | Power |
| POWER OFF | Main Power Off | SHIFT + | Shift + Power |
| SOURCE POWER | Source Power | OK | OK |
| PHONO | Phono | SHIFT + TV 1 | Shift + 1 |
| CD | CD | SHIFT + CD-STB 3 | Shift + 3 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| CD-R | CD-R | SHIFT + USB 8 | Shift + 8 |
| AUX | AUX | SHIFT + AUX-HDD 7 | Shift + 7 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TAPE | Tape | SHIFT + TAPE 5 | Shift + 5 |
| MD | MD | SHIFT + VIDEO 4 | Shift + 4 |
| 1 | 1 CD | TV 1 | 1 |
| 2 | 2 CD | DVD 2 | 2 |
| 3 | 3 CD | CD-STB 3 | 3 |
| A F/P | A / F/P CD | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 4 | 4 CD | VIDEO 4 | 4 |
| 5 | 5 CD | TAPE 5 | 5 |

| Original | | Rechange | |
|---|---|---|---|
| 6 | 6 CD | TUNER 6 | 6 |
| B-/-- | B/--/-- CD | Prime Video RANDOM | Blue / Prime Video / Random |
| 7 | 7 CD | AUX-HDD 7 | 7 |
| 8 | 8 CD | USB 8 | 8 |
| 9 | 9 CD | BLUETOOTH 9 | 9 |
| MODE | Mode CD | LIST SMART | Smart / List |
| - | - CD | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 CD | HDMI-SAT 0 | 0 |
| + | + CD | PC FAV MARKER | Fav / Marker / PC |
| MEMO | Memo CD | MEDIA DISPLAY | Display / Media |
| SCROLL | Scroll CD | ANGLE INFO | Info / Angle |
| CANCEL | Cancel CD | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| B-M TEXT | 1 Mode/Text CD | NETFLIX SEARCH | Red / Netflix / Search |
| DE-2 TIME | 2 Mode/Time | APP REPEAT | Green / APP / Repeat |
| ⏮ | I<< CD | PRESET- ⏮ | I<< / Preset- |
| ▶ | Play CD | SLOW ▶ | Play / Slow |
| ⏭ | >>I CD | PRESET+ ⏭ | >>I / Preset+ |

| Original | | Rechange | |
|---|---|---|---|
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| ◀◀ | << CD | TUNE- ◀◀ | << / Tune- |
| ■ | Stop CD | HOLD ■ | Stop / Hold |
| ▶▶ | >> CD | TUNE+ ▶▶ | >> / Tune+ |
| VOLUME ▲ | Volume Up | VOL + | Vol + |
| ❚❚ | Pause CD | STEP-FREEZE ❚❚ | Pause / Step / Freeze |
| OPEN/ CLOSE | Open/Close CD | SURROUND ⏏ | Eject / Surround |
| VOLUME ▼ | Volume Down | VOL − | Vol - |
| SOURCE POWER | Source Power | SHIFT + OK | Shift + OK |
| + | + AUX | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| − | - AUX | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| ▶ | Play AUX | SHIFT + SLOW ▶ | Shift + Play / |
| ■ | Stop AUX | SHIFT + HOLD ■ | Shift + Stop / |
| ▶▶I | >>I AUX | SHIFT + PRESET+ ▶▶I | Shift + >>I / Preset+ |
| I◀◀ | I<< AUX | SHIFT + PRESET- I◀◀ | Shift + I<< / Preset- |
| ▶▶ | >> AUX | SHIFT + TUNE+ ▶▶ | Shift + >> / |
| ◀◀ | << AUX | SHIFT + TUNE- ◀◀ | Shift + << / Tune- |

| Original | | Rechange | |
|---|---|---|---|
| ❚❚ | Pause AUX | SHIFT + STEP-FREEZE ❚❚ | Shift + Pause / Step / |
| OPEN/ CLOSE | Open/Close AUX | SHIFT + SURROUND ⏏ | Shift + Eject / Surround |
| ◀▶ | <> AUX | SHIFT + REC MODE ● | Shift + Rec / Rec Mode |
| 1-M TEXT | 1 Mode/Text | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| DE-2 TIME | 2 Mode/Time | SHIFT + APP REPEAT | Shift + Green / APP / |
| MEMO | Memo AUX | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| MODE | Mode AUX | SHIFT + LIST SMART | Shift + Smart / List |
| B -/-- | B/--/-- AUX | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| A F/P | A / F/P AUX | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |