Original	Rechange	Original	Rechange
Power	Power	Right	Right
SD/HC	Display / Media	Option	Setup / OPT /
Input TV	Shift + 1	Down	Down
Input TV	TV/Radio /	Back/Return	Back / Return
Input AV	AV / Input / RDS	Red	Red / Netflix / Search
[+]/Aspect	Picture / Format	Green	Green / APP / Repeat
Menu	Menu / Home	Yellow	Yellow / YouTube / Repeat
N	Audio / Lang I/II	Blue	Blue / Prime Video / Random
Direct Tv Rec	Shift + Rec / Rec Mode	Text	Text / Goto
i	Info / Angle	STTL	Subtitle / EQ
Exit	Exit / Cancel / Clear	Index	Zoom / Size
Viera Tools	D.Menu / Top	Hold	Shift + Stop /
Viera Link	Smart / List	1	1
Up	Up	2	2
Guide	Guide / EPG / -/--	3	3
Left	Left	4	4
OK	OK	5	5

Original		Rechange	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
Mute	Mute	DIMMER MUTE	Mute / Dimmer
0	0	0	0
(<>)	(<>)	TITLE SOUND	Sound / Title
Vol +	Vol +	+ VOL	Vol +
CH+	CH+	+ CH PAGE	CH+ / Page+
Vol -	Vol -	VOL -	Vol -
CH-	CH-	CH PAGE -	CH- / Page-
Power Down	Power Down	SHIFT + Power	Shift + Power
REC	Rec	REC MODE	Rec / Rec Mode
PROGR	Programme	SHIFT + CH PAGE -	Shift + CH- /
RAMME	Programme Up	SHIFT + CH PAGE +	Shift + CH+ /
<<	<<	TUNE-	<< / Tune-
I <<	I <<	PRESET-	I << / Preset-

Original		Rechange	
Play	Play	SLOW	Play / Slow
>>	>>	TUNE+	>> / Tune+
>>I	>>I	PRESET+	>>I / Preset+
Stop	Stop	HOLD	Stop / Hold
DVD Pause/Step	Pause/Step	STEP-FREEZE	Pause / Step / Freeze

Original		Rechange	
	Power Down		Power
REC	Rec	REC MODE	Rec / Rec Mode
PROGR	Programme	CH PAGE	CH- / Page-
RAMME	Programme Up	CH PAGE	CH+ / Page+
	<<	TUNE-	<< / Tune-
	I <<	PRESET-	I << / Preset-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	>>I	PRESET+	>>I / Preset+
	Stop	HOLD	Stop / Hold
	Pause/ Step	STEP-FREEZE	Pause / Step / Freeze

Original	Rechange