Original		Rechange	
ON/STANDBY	On/Standby		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
DVD/BD	DVD / BD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL/SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	Game	SHIFT + BLUETOOTH 9	Shift + 9
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TV/TAPE	TV / TAPE	SHIFT + TAPE 5	Shift + 5
TV/TAPE	TV / TAPE	SHIFT + TV 1	Shift + 1
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
PORT	PORT	SHIFT + USB 8	Shift + 8
CD	CD	SHIFT + CD - STB 3	Shift + 3
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CH DISC	CH/Disc/Album	CH PAGE +	CH+ / Page+
VOL	Vol +	VOL +	Vol +
ALBUM	CH/Disc/Album-	CH PAGE −	CH- / Page-
VOL	Vol -	VOL −	Vol -

Original		Rechange	
	Up		Up
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause	STEP - FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie Tv	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat

Original	Rechange	Original	Rechange
Game	Yellow / YouTube / Repeat		
Stereo	Blue / Prime Video / Random		
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
+10/--/---10/Dimer/D.Tun	Guide / EPG / -/--		
0/11	0		
CLR/Sleep/12	Fav / Marker / PC		
CLR/Sleep/12	Sleep / Timer		
CLR/Sleep/12	Exit / Cancel / Clear		

Original		Rechange	
	Power BD/DVD		Power
	DVD/BD		Smart / List
	CBL/SAT		Display / Media
	Vol + Receiver		Vol +
	Vol - Receiver		Vol -
	Top Menu		D.Menu / Top
	Up BD/DVD		Up
	Menu BD/DVD		Menu / Home
	Left BD/DVD		Left
	Enter BD/DVD		OK
	Right BD/DVD		Right
	Setup BD/DVD		Setup / OPT /
	Down BD/DVD		Down
	Return BD/DVD		Back / Return
	Audio BD/DVD		Audio / Lang I/II
	I<< BD/DVD		I<< / Preset-
	>>I BD/DVD		>>I / Preset+

Original		Rechange	
	<< BD/DVD		<< / Tune-
	Play BD/DVD		Play / Slow
	>> BD/DVD		>> / Tune+
	Pause BD/DVD		Pause / Step / Freeze
	Stop BD/DVD		Stop / Hold
	Search BD/DVD		Red / Netflix / Search
	Repeat BD/DVD		Green / APP / Repeat
	Random		Blue / Prime Video / Random
	Play Mode		Yellow / YouTube / Repeat
	1 BD/DVD		1
	2 BD/DVD		2
	3 BD/DVD		3
	4 BD/DVD		4
	5 BD/DVD		5
	6 BD/DVD		6
	7 BD/DVD		7
	8 BD/DVD		8

Original		Rechange	
9	9 BD/DVD	BLUETOOTH 9	9
+10 DIMMER	+10/--/--10	-/-- GUIDE EPG	Guide / EPG / -/--
0 11	0/11 BD/DVD	HDMI - SAT 0	0
CLR 12 SLEEP	CLR/12 BD/DVD	PC FAV MARKER	Fav / Marker / PC
CLR 12 SLEEP	CLR/12 BD/DVD	CLEAR EXIT CANCEL	Exit / Cancel / Clear
ON/STANDBY	Power CBL/SAT	SHIFT +	Shift + Power
CH DISC	CH Disc/Album+ CBL/SAT	SHIFT + CH PAGE +	Shift + CH+ /
ALBUM	CH Disc/Album- CBL/SAT	SHIFT + CH PAGE -	Shift + CH- /
GUIDE/TOP MENU	Guide CBL/SAT	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
	Up CBL/SAT	SHIFT +	Shift + Up
PREV CH/MENU VIDEO	Menu/Prev CH CBL/SAT	SHIFT + HOME MENU	Shift + Menu /
PLAYLIST /CATEGORY	Left CBL/SAT	SHIFT +	Shift + Left
ENTER	Enter CBL/SAT	SHIFT + OK	Shift + OK
PLAYLIST /CATEGORY	Right CBL/SAT	SHIFT +	Shift + Right
SETUP	Setup CBL/SAT	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Down CBL/SAT	SHIFT +	Shift + Down
RETURN	Return CBL/SAT	SHIFT + RETURN BACK	Shift + Back / Return

Original		Rechange	
	<< CBL/SAT	SHIFT + TUNE-	Shift + << /
	Play CBL/SAT	SHIFT + SLOW	Shift + Play /
	>> CBL/SAT	SHIFT + TUNE+	Shift + >> /
	Pause CBL/SAT	SHIFT + STEP - FREEZE	Shift + Pause / Step /
	Stop CBL/SAT	SHIFT + HOLD	Shift + Stop /
MOVIE/TV SEARCH	Movie Tv/Search CBL/SAT	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
LISTENI MUSIC REPEAT	Music/Repeat CBL/SAT	SHIFT + APP REPEAT	Shift + Green / APP /
GAME RANDOM	Game/Random	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /
STEREO PLAY MODE	Stereo/Play Mode CBL/SAT	SHIFT + Prime Video RANDOM	Shift + Blue / Prime
1	1 CBL/SAT	SHIFT + TV 1	Shift + 1
2	2 CBL/SAT	SHIFT + DVD 2	Shift + 2
3	3 CBL/SAT	SHIFT + CD - STB 3	Shift + 3
4	4 CBL/SAT	SHIFT + VIDEO 4	Shift + 4
5	5 CBL/SAT	SHIFT + TAPE 5	Shift + 5
6	6 CBL/SAT	SHIFT + TUNER 6	Shift + 6
7	7 CBL/SAT	SHIFT + AUX - HDD 7	Shift + 7
8	8 CBL/SAT	SHIFT + USB 8	Shift + 8

Original	Rechange	Original	Rechange
9 CBL/SAT	SHIFT + BLUETOOTH 9 Shift + 9		
0/11 CBL/SAT	SHIFT + HDMI - SAT 0 Shift + 0		

Original		Rechange	
	Power CD		Power
	CD		Smart / List
	CH/Disc+ CD		CH+ / Page+
	Vol + Receiver		Vol +
	CH/Disc- CD		CH- / Page-
	Vol - Receiver		Vol -
	Up CD		Up
	Left CD		Left
	Enter CD		OK
	Right CD		Right
	Setup CD		Setup / OPT /
	Down CD		Down
	Return CD		Back / Return
	Audio CD		Audio / Lang I/II
	I<< CD		I<< / Preset-
	>>I CD		>>I / Preset+
	<< CD		<< / Tune-

Original		Rechange	
	Play CD		Play / Slow
	>> CD		>> / Tune+
	Pause CD		Pause / Step / Freeze
	Stop CD		Stop / Hold
	Search CD		Red / Netflix / Search
	Repeat CD		Green / APP / Repeat
	Random CD		Blue / Prime Video / Random
	Play Mode CD		Yellow / YouTube / Repeat
	1 CD		1
	2 CD		2
	3 CD		3
	4 CD		4
	5 CD		5
	6 CD		6
	7 CD		7
	8 CD		8
	9 CD		9

Original	Rechange	Original	Rechange
+10/--/--10/D.Tu Dimmer CD	Guide / EPG / -/--		
0/11 CD	0		
CLR/Sleep/12	Fav / Marker / PC		

Original		Rechange	
	Power Receiver Zone 2		Power
	CH Disc/Album+ Zone 2		CH+ / Page+
	Vol + Zone 2		Vol +
	CH Disc/Album- Zone 2		CH- / Page-
	Vol - Zone 2		Vol -
	Up Zone 2		Up
	Left Zone 2		Left
	Enter Zone 2		OK
	Right Zone 2		Right
	Setup Zone 2		Setup / OPT /
	Down Zone 2		Down
	Return Zone 2		Back / Return
	Audio Zone 2		Audio / Lang I/II
	I<< Zone 2		I<< / Preset-
	>>I Zone 2		>>I / Preset+
	<< Zone 2		<< / Tune-
	Play Zone 2		Play / Slow

Original		Rechange	
	>> Zone 2		>> / Tune+
	Pause Zone 2		Pause / Step / Freeze
	Stop Zone 2		Stop / Hold
	Movie Tv Zone		Red / Netflix / Search
	Music Zone 2		Green / APP / Repeat
	Game Zone 2		Yellow / YouTube / Repeat
	Stereo Zone 2		Blue / Prime Video / Random
	1 Zone 2		1
	2 Zone 2		2
	3 Zone 2		3
	4 Zone 2		4
	5 Zone 2		5
	6 Zone 2		6
	7 Zone 2		7
	8 Zone 2		8
	9 Zone 2		9
	+10/--/--10/D.Tuning Dimmer Zone 2		Guide / EPG / -/--

Original		Rechange		Original		Rechange	
0	0/11 Zone 2	0	0				
CLR SLEEP	CLR/Sleep/12	FAV MARKER	Fav / Marker / PC				