Original	Rechange	Original	Rechange
Muting Receiver	Mute	Stop Receiver	Stop
Power Receiver	Power	1 Receiver	1
Display	Info	2 Receiver	2
Enter Receiver	Ok	3 Receiver	3
Up Receiver	Up	4 Receiver	4
Down Receiver	Down	5 Receiver	5
Right Receiver	Right	6 Receiver	6
Left Receiver	Left	7 Receiver	7
Return Receiver	Back	8 Receiver	8
Setup Receiver	Smart	9 Receiver	9
Audio/Home	Media	0/11 Receiver	0
Play Receiver	Play	+10/---/---10/Dimer/D.Tun Receive	Shift + Guide
<< Receiver	<<	CLR/Sleep/12 Receiver	Pre Ch
>>| Receiver	>>|	Movie Tv/Search Receiver	Red
<< Receiver	<<	Music/Repeat Receiver	Green
>> Receiver	>>	Game/Random Receiver	Yellow
Pause/Play reverse Receiver	Pause	THX/Play Mode Receiver	Blue

Original		Rechange	
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL −	Vol -
CH DISC	CH/Disc/Album+ Receiver	+ CH	Ch +
ALBUM	CH/Disc/Album Receiver	CH −	Ch -
TV	Power Tv	SHIFT +	Shift + Power
TV INPUT	Input Tv	TIMER AV	AV
CH DISC	CH+ Tv	SHIFT + + CH	Shift + Ch +
ALBUM	CH- Tv	SHIFT + CH −	Shift + Ch -
	Up Tv	SHIFT +	Shift + Up
ENTER	Enter Tv	SHIFT + OK	Shift + Ok
	Down Tv	SHIFT +	Shift + Down
PLAYLIST	Right Tv	SHIFT +	Shift + Right
PLAYLIST	Left Tv	SHIFT +	Shift + Left
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Guide/Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return Tv	SHIFT + RETURN BACK	Shift + Back
Q SETUP	Setup Tv	SHIFT + HOME SMART	Shift + Smart

Original		Rechange	
SEARCH MOVIE/TV A	Movie/TV/Search	SETTINGS OPT	Options
REPEAT MUSIC B	Music/Repeat	SOUND DUAL	Dual
RANDOM GAME C	Game/Random	AD SUBT	Subt
MODE THX D	Stereo/Play Mode	SEARCH TV/R	TV/R
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
11 0	0/11 Tv	SHIFT + 0	Shift + 0
+10 D.TUN DIMMER	+10/--/--10 Tv	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	SHIFT + FAV PRE-CH	Shift + Pre Ch
VOL	Vol + Tv	SHIFT + SOUND DUAL	Shift + Dual

Original		Rechange		Original		Rechange
VOL	Vol - Tv	SHIFT + SETTINGS OPT	Shift + Options			
AUX	AUX	REPEAT TEXT	Text			
TV/CD	TV / CD	PICTURE FORMAT	Format			
CBL/SAT	CBL/SAT	ECO 3D	3D			
FM	FM	SHIFT + AD SUBT	Shift + Subt			
BD/DVD	DVD / BD	SHIFT + REPEAT TEXT	Shift + Text			
GAME	Game	SHIFT + SEARCH TV/R	Shift + TV/R			
STB/DVR	VCR / DVR	SHIFT + TIMER AV	Shift + AV			
PC	PC	ZOOM ⏏	Eject			
USB	USB	DISC NAV LIST	List			
NET	NET	SHIFT + ZOOM ⏏	Shift + Eject			

Original		Rechange	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Setup BD/DVD	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
PLAYLIST	Right BD/DVD		Right
PLAYLIST	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
	Play BD/DVD	PLAY MODE	Play
	Pause/Play rev. BD/DVD		Pause

Original		Rechange	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Search BD/DVD	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
10 11 0	0/11 BD/DVD	0	0
+10 D.TUN DIMMER	+10/--/--10/D.Tuning Dimmer BD/DVD	GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Original	Rechange	Original	Rechange
CBL/SAT — CBL/SAT	REPEAT TEXT — Text	<< CBL/SAT — << CBL/SAT	SHIFT + CH − — Shift + Ch -
Vol + Receiver — VOL +	VOL + — Vol +	>> CBL/SAT — >> CBL/SAT	SHIFT + CH + — Shift + Ch +
Vol - Receiver — VOL −	VOL − — Vol -	Play CBL/SAT — Play CBL/SAT	ECO 3D — 3D
Power CBL/SAT — SOURCE	SHIFT + — Shift + Power	Movie Tv/Search CBL/SAT — SEARCH MOVIE/TV A	SOUND DUAL — Dual
CH Disc/Album+ CBL/SAT — CH DISC	CH + — Ch +	Music/Repeat CBL/SAT — REPEAT MUSIC B	AD SUBT — Subt
CH Disc/Album- CBL/SAT — ALBUM	CH − — Ch -	Game/Random — RANDOM GAME C	TIMER AV — AV
Menu/Prev CH CBL/SAT — MENU PREV CH	SHIFT + TOP MENU MENU — Shift + Menu	Stereo/Play Mode CBL/SAT — MODE THX D	PICTURE FORMAT — Format
Top Menu/Guide CBL/SAT — TOP MENU GUIDE	SHIFT + SETTINGS OPT — Shift + Options	1 CBL/SAT — 1	SHIFT + 1 — Shift + 1
Return CBL/SAT — RETURN	SHIFT + RETURN BACK — Shift + Back	2 CBL/SAT — 2	SHIFT + 2 — Shift + 2
Setup CBL/SAT — Q SETUP	SHIFT + HOME SMART — Shift + Smart	3 CBL/SAT — 3	SHIFT + 3 — Shift + 3
Up CBL/SAT —	SHIFT + ▲ — Shift + Up	4 CBL/SAT — 4	SHIFT + 4 — Shift + 4
Enter CBL/SAT — ENTER	SHIFT + OK — Shift + Ok	5 CBL/SAT — 5	SHIFT + 5 — Shift + 5
Down CBL/SAT —	SHIFT + ▼ — Shift + Down	6 CBL/SAT — 6	SHIFT + 6 — Shift + 6
Right CBL/SAT — PLAYLIST	SHIFT + ▶ — Shift + Right	7 CBL/SAT — 7	SHIFT + 7 — Shift + 7
Left CBL/SAT — PLAYLIST	SHIFT + ◀ — Shift + Left	8 CBL/SAT — 8	SHIFT + 8 — Shift + 8
Pause/Play rev. CBL/SAT —	SHIFT + ⏸ — Shift + Pause	9 CBL/SAT — 9	SHIFT + 9 — Shift + 9
Stop CBL/SAT —	SHIFT + ■ — Shift + Stop	0/11 CBL/SAT — 0 11	SHIFT + 0 — Shift + 0

Original	Rechange	Original	Rechange
BD/DVD DVD/ BD	SEARCH TV/R TV/ R		

Original		Rechange	
SOURCE	Power CD		Power
CH DISC	CH/Disc+ CD	CH	Ch +
ALBUM	CH/Disc- CD	CH	Ch -
RETURN	Return CD	RETURN BACK	Back
SETUP	Setup CD	HOME SMART	Smart
AUDIO HOME	Home/Audio CD	APP MEDIA	Media
	Up CD		Up
	Down CD		Down
PLAYLIST	Right CD		Right
PLAYLIST	Left CD		Left
ENTER	Enter CD	OK	Ok
	I<< CD		I<<
	>>I CD		>>I
	<< CD		<<
	>> CD		>>
	Play CD	PLAY MODE	Play
	Pause CD		Pause

Original		Rechange	
	Stop CD		Stop
SEARCH MOVIE/TV A	Movie Tv/Search	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode	D	Blue
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
10 11 0	0/11 CD	0	0
+10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer CD	GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Original	Rechange	Original	Rechange
VOL Vol + Recei ver	+ VOL Vol +		
VOL Vol - Recei ver	VOL − Vol -		
TV/CD TV/ CD	SEARCH TV/R TV/ R		

Original		Rechange	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	VOL	Vol +
VOL	Vol - Zone 2	VOL	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH	Ch +
ALBUM	CH Disc/Album- Zone 2	CH	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
PLAYLIST	Right Zone 2		Right
PLAYLIST	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
SETUP	Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Audio Zone 2	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Original		Rechange	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Search Zone 2	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
0 11	0/11 Zone 2	0	0

Original	Rechange	Original	Rechange
+10/- - /- - 10/D.Tu Dimmer Zone 2	Guide		
CLR/Sleep/12	Pre Ch		