Mandis shop

Telefunken DPF10333



Original		Rechange	
	Up		Up
	Sleep	TIMER SLEEP	Sleep / Timer
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
STOP	Stop	HOLD	Stop / Hold
	Mute	DIMMER MUTE	Mute / Dimmer
	Vol+	VOL +	Vol+
COPY/DEL	Copy/Del	RETURN BACK	Back / Return
ROTATE	Rotate	LIST SMART	Smart / List
	Zoom	SIZE ZOOM	Zoom / Size
	Vol-	VOL −	Vol-
SLIDE SHOW	Slide Show	MEDIA DISPLAY	Display / Media
MUSIC	Music	TITLE SOUND	Sound / Title
VIDEO	Video	FORMAT PICTURE	Picture / Format

Original		Rechange	
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /



https://remote-controls.ch/fr/Telefunken/1066143-92321-telecommande-de-remplacement-pour-Telefunken-DPF10333.html