Original		Rechange	
	Power		Power
OPEN/ CLOSE	Open/Close	SURROUND	Eject / Surround
FUNCTION	Function	LIST SMART	Smart / List
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
0	0	HDMI-SAT 0	0
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
SKIP I◀◀	I<<	PRESET-	I<< / Preset-
SCAN ◀◀	<<	TUNE-	<< / Tune-

Original		Rechange	
SCAN ▶▶	>>	TUNE+	>> / Tune+
SKIP ▶▶I	>>I	PRESET+	>>I / Preset+
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
SPEAKER LEVEL	Speaker Level	PROGRAM TV/ RADIO	TV/Radio /
VOL +	Vol +	VOL +	Vol +
OPTICAL	Optical / Tv Sou	OPT-TOOLS SETUP	Setup / OPT /
SOUND EFFECT	Sound Effect	TITLE SOUND	Sound / Title
VOL -	Vol -	VOL -	Vol -
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
HOME	Home	HOME MENU	Menu / Home
SOUND ZOOM	3D Sound	SIZE ZOOM	Zoom / Size
INFO/ MENU	Info/Menu	ANGLE INFO	Info / Angle
	Up/Preset+		Up
	Left/Tuning-		Left
ENTER	Enter	OK	OK

Original	Rechange	Original	Rechange
Right / Tuning+	Right	AV Input Tv	AV / Input / RDS
Down / Preset-	Down	Volum- Tv	Shift + Vol -
Back	Back / Return	PR/CH- Tv	CH- / Page-
Title / Pop Up	Picture / Format		
Disc Menu	D.Menu / Top		
Red / RDS	Red / Netflix / Search		
Green / PTY	Green / APP / Repeat		
Yellow / PTY Searc	Yellow / YouTube / Repeat		
Blue / Mono / Stereo	Blue / Prime Video / Random		
Subtitle	Subtitle / EQ		
Audio	Audio / Lang I/II		
Sleep	Sleep / Timer		
Music ID	Text / Goto		
*	Display / Media		
Power Tv	Shift + Power		
Volum+ Tv	Shift + Vol +		
PR/CH+ Tv	CH+ / Page+		