

Original	Rechange	Original	Rechange
Power CD	Power	Setup AMP	Shift + Setup / OPT / Tools
Power AMP	Shift + Power	Pause	Pause / Step / Freeze
Up CD	Up	I<<	I<< / Preset-
Up AMP	Shift + Up	Play	Play / Slow
Left CD	Left	>>I	>>I / Preset+
Left AMP	Shift + Left	Stop	Stop / Hold
Enter CD	OK	Info	Info / Angle
Enter AMP	Shift + OK	Disc/Input	AV / Input / RDS
Right CD	Right	Open/Close	Eject / Surround
Right AMP	Shift + Right	Input Up	CH+ / Page+
Down CD	Down	Tone	Display / Media
Down AMP	Shift + Down	Volume Up	Vol+
Display CD	Smart / List	Input Down	CH- / Page-
Display AMP	Shift + Smart / List	Volume Down	Vol-
Mode/Trim CD	Picture / Format	Mute	Mute / Dimmer
Mode/Trim AMP	Shift + Picture / Format	1	1
Setup CD	Setup / OPT / Tools	2	2





Original		Rechange	
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10	+10	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
PROGRAM	Program	SHIFT + PROGRAM TV/ RADIO	Shift + TV/Radio / Program
FILTER	Filter	NETFLIX SEARCH	Red / Netflix / Search
SOUND MODE	Sound Mode	TITLE SOUND	Sound / Title
DIGITAL OUT	Digital Out	PROGRAM TV/ RADIO	TV/Radio /

Original	Rechange

