Original		Rechange	
Standby	Standby	Power	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
	World	LIST SMART	Smart / List
TV/Radio	TV/Radio	PROGRAM TV/RADIO	TV/Radio /
TEXT	Text	GOTO TEXT	Text / Goto
	Mail	MEDIA DISPLAY	Display / Media
LIB	Lib	TOP MENU D.MENU	D.Menu / Top
TIMERS	Timers	TIMER SLEEP	Sleep / Timer
1	1	TV 1	1
2abc	2	DVD 2	2
3def	3	CD-STB 3	3
4ghi	4	VIDEO 4	4
5jkl	5	TAPE 5	5
6mno	6	TUNER 6	6
7pqrs	7	AUX-HDD 7	7
8tuv	8	USB 8	8

Original		Rechange	
9wxyz	9	BLUETOOTH 9	9
	Music/Movie/Phot	TITLE SOUND	Sound / Title
AV 0	0/AV	HDMI-SAT 0	0
INFO	Info	ANGLE INFO	Info / Angle
VOL+	Vol +	+ VOL	Vol +
P↔P	P↔P	SIZE ZOOM	Zoom / Size
P+	P+	+ CH PAGE	CH+ / Page+
VOL–	Vol -	VOL –	Vol -
OPT	Opt	OPT-TOOLS SETUP	Setup / OPT /
P–	P-	CH PAGE –	CH- / Page-
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Rechange	
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
BACK	Back	RETURN BACK	Back / Return
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
	Stop	HOLD	Stop / Hold
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Rec	REC MODE	Rec / Rec Mode

Original	Rechange