Original	Rechange		Original	Rechange	
On/Off		Power	Exit		Exit
Audio Out		Mute	Menu Down		Down
Slow Down		Shift + Pause	Tracking+		Ch +
F. Adv		List	Audio		Dual
Auto/Track		Smart	Tracking-		Ch -
Stop		Stop	1		1
Pause		Pause	Next		>>I
Slow/Dpss-		Vol -	2		2
Mon/TV		TV/R	Otr/A.Otr		Blue
Video/Go-To		D. Menu	3		3
Sp/Lp/Speed		Text	X2 Rew/Play		Subt
VCR/TV		AV	P. Back/R. +Play		Back
Menu		Menu	4		4
Menu Up		Up	Vps/Pdc		Ok
Slow/Dpss+		Vol +	Prev.		I<<
Display		Info	5		5
T. Set/Clock		Yellow	Store		Media

Original	Rechange
6	6
7	7
8	8
9	9
-/--	Guide
Rec. On/Off	Options
0	0
Clear 00:00	Shift + Exit
Rec/Mode	Shift + Rec
Progr/C/CH	Pre Ch
Skip/Search	Format
F. Forward	>>
Play	Play
Counter Reset	Green
Eject/Reverse	Eject
Search Index	Shift + TV/R
Timer/Record	Shift + AV

Original	Rechange
Rewind	<<
Timer/Sleep	Sleep
Record	Rec
Counter Clock	Red