Original		Rechange	
	Power		Power
DVD	DVD	SHIFT + DVD 2	Shift + 2
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
RETURN	Return	RETURN BACK	Back / Return
0	0	HDMI - SAT 0	0
DISPLAY	Display	MEDIA DISPLAY	Display / Media
DISC MENU	Disc Menu	TOP MENU D.MENU	D. Menu / Top
	Up		Up

Original		Rechange	
SYSTEM MENU	System Menu	HOME MENU	Menu / Home
	Left		Left
OK	OK	OK	OK
	Right		Right
	I<<	PRESET-	I<< / Preset-
	Down		Down
	>>I	PRESET+	>>I / Preset+
STOP	Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow
PAUSE/STEP	Pause / Step	STEP - FREEZE	Pause / Step / Freeze
MARKER	Marker	PC FAV MARKER	Fav / Marker / PC
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ANGLE	Angle	ANGLE INFO	Info / Angle
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original	Rechange	Original	Rechange
REPEAT A-B Repeat A-B	YouTube REPEAT A-B Yellow / YouTube / Repeat		
PROGRAM Program	PROGRAM TV/RADIO TV/Radio /		
CLEAR Clear	CLEAR EXIT CANCEL Exit / Cancel / Clear		
TITLE Title	TITLE SOUND Sound / Title		
SHUFFLE Shuffle	Prime Video RANDOM Blue / Prime Video / Random		

Original		Rechange	
	Power		Power
TV/VIDEO	TV / Video	OPT-TOOLS SETUP	Setup / OPT /
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
OPEN/CLOSE	Eject	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
DISPLAY	Display	MEDIA DISPLAY	Display / Media
	Up		Up
SYSTEM MENU	System Menu	HOME MENU	Menu / Home

Original		Rechange	
	Left		Left
OK	OK	OK	OK
	Right		Right
	I<<	PRESET-	I<< / Preset-
	Down		Down
	>>I	PRESET+	>>I / Preset+
STOP	Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow
PAUSE/STEP	Pause / Step	STEP-FREEZE	Pause / Step / Freeze
MARKER	Marker	PC FAV MARKER	Fav / Marker / PC
SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search
INPUT	Input	RDS AV INPUT	AV / Input / RDS
RECORD	Record	REC MODE	Rec / Rec Mode
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
TITLE	Title	TITLE SOUND	Sound / Title
CHILD LOCK	Child Lock	SIZE ZOOM	Zoom / Size