Original		Rechange	
OFF/ON	Off / On		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CD	CD Easy Play	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TAPE	Tape Easy Play	NETFLIX SEARCH	Red / Netflix / Search
TUNER	Tuner Easy Play	APP REPEAT	Green / APP / Repeat
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD·STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX·HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI·SAT 0	0
PROGRAM	Program CD	OPT-TOOLS SETUP	Setup / OPT /
CANCEL	Cancel CD	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Rechange	
CD	CD	SHIFT + CD·STB 3	Shift + 3
TUNER/ BAND	Tuner / Band	SHIFT + TUNER 6	Shift + 6
≥10	>10	-/-- GUIDE EPG	Guide / EPG / -/--
▶	Play CD	SLOW ▶	Play / Slow
⏸	Pause CD	STEP·FREEZE ⏸	Pause / Step / Freeze
■	Stop CD	HOLD ■	Stop / Hold
⏮	I<< CD	PRESET- ⏮	I<< / Preset-
⏭	>>I CD	PRESET+ ⏭	>>I / Preset+
REC PAUSE	Rec Pause Tape	REC MODE ●	Rec / Rec Mode
DECK 1/2	Deck 1/2 Tape	SHIFT + TAPE 5	Shift + 5
EQ·S ON/FLAT	On/Flat EQ. Space	LANG I/II AUDIO	Audio / Lang I/II
PACE MODE	Mode EQ. Space	EQ SUBTITLE	Subtitle / EQ
V. BASS	V. Bass	TITLE SOUND	Sound / Title
◀	< Tape	◀	Left
■	Stop Tape	OK	OK
▶	> Tape	▶	Right
◀◀	<< Tape	TUNE- ◀◀	<< / Tune-

Original		Rechange	
	>> Tape		>> / Tune+
	Muting -20dB		Mute / Dimmer
	Volume-		Vol -
	Volume+		Vol +

Original	Rechange