| Original | | Rechange | |
|---|---|---|---|
| | Open/Close | SURROUND | Eject / Surround |
| | Power | | Power |
| ZOOM RED | Red/Zoom | NETFLIX SEARCH | Red / Netflix / Search |
| PROGRAM GREEN | Green/Program | APP REPEAT | Green / APP / Repeat |
| SHUFFLE YELLOW | Yellow/Shuffle | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| REPEAT BLUE | Blue/Repeat | Prime Video RANDOM | Blue / Prime Video / Random |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI-SAT 0 | 0 |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Original | | Rechange | |
|---|---|---|---|
| SEARCH | Search | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| REPEAT A/B | Repeat A/B | SHIFT + APP REPEAT | Shift + Green / APP / |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| ANGLE | Angle | ANGLE INFO | Info / Angle |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| PIP | PIP | FORMAT PICTURE | Picture / Format |
| 2ND AUDIO | 2nd Audio | DIMMER MUTE | Mute / Dimmer |
| MIRACAST | Miracast | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| HOME | Home | HOME MENU | Menu / Home |
| YouTube | YouTube | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| vidi | Vidi | GOTO TEXT | Text / Goto |
| TOP MENU | Top Menu | TOP MENU D.MENU | D.Menu / Top |
| POP-UP/MENU | Pop-Up Menu | LIST SMART | Smart / List |
| RETURN | Return | SHIFT + RETURN BACK | Shift + Back / Return |
| ON SCREEN | On Screen | MEDIA DISPLAY | Display / Media |
| | Up | | Up |
| | Down | | Down |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| Left | Left | | |
| Right | Right | | |
| Enter | OK | | |
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| Play | Play / Slow | | |
| <<I | CH- / Page- | | |
| I >> | CH+ / Page+ | | |
| << | << / Tune- | | |
| >> | >> / Tune+ | | |
| Setup | Setup / OPT / | | |
| Status | Back / Return | | |
| I << | I << / Preset- | | |
| >>I | >>I / Preset+ | | |
| | | | |
| | | | |
| | | | |