Originale		Sostituto	
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
POWER	Power	POWER	Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
GOTO	Goto	GOTO TEXT	Text / Goto
0	0	HDMI - SAT 0	0
Clear	Clear	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
OSC	OSC	TITLE SOUND	Sound / Title
TOP MENU	Top Menu	TOP MENU D.MENU	D. Menu / Top
PIP	PIP	FORMAT PICTURE	Picture / Format

Originale		Sostituto	
POP UP/MENU	Pop Up/Menu	LIST SMART	Smart / List
REV	<<	TUNE-	<< / Tune-
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
FWD	>>	TUNE+	>> / Tune+
SKIP	I<<	PRESET-	I<< / Preset-
STOP	Stop	HOLD	Stop / Hold
SKIP	>>I	PRESET+	>>I / Preset+
HOME	Home	HOME MENU	Menu / Home
SETTING	Setting	OPT-TOOLS SETUP	Setup / OPT /
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
STEP/SLOW	Step/Slow	SHIFT + SLOW	Shift + Play /
STEP/SLOW	Step/Slow	SHIFT + STEP - FREEZE	Shift + Pause / Step /
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right

Originale		Sostituto		Originale	Sostituto
RETURN	Return	RETURN BACK	Back / Return		
	Down		Down		
PROGRAM	Red/Program	NETFLIX SEARCH	Red / Netflix / Search		
PROGRAM	Red/Program	PROGRAM TV/RADIO	TV/Radio /		
DIGEST	Green/Digest	APP REPEAT	Green / APP / Repeat		
ZOOM	Yellow/Zoom	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
ZOOM	Yellow/Zoom	SIZE ZOOM	Zoom / Size		
BOOKMARK	Blue/Bookmark	Prime Video RANDOM	Blue / Prime Video / Random		
SUB	Sub	EQ SUBTITLE	Subtitle / EQ		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
2nd. AUDIO	2nd. Audio	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
ANGLE	Angle	ANGLE INFO	Info / Angle		
A-B	A-B	SHIFT + YouTube REPEAT A-B	Shift + Yellow / YouTube /		
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /		
DISPLAY	Display	MEDIA DISPLAY	Display / Media		