Originale		Sostituto	
POWER	Power		Power
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat
A-B	A-B	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
OPEN/CLOSE	Open / Close	SURROUND	Eject / Surround
N/P	N / P	GOTO / TEXT	Text / Goto
1	1	TV / 1	1
2	2	DVD / 2	2
3	3	CD - STB / 3	3
SUBTITLE	Subtitle	EQ / SUBTITLE	Subtitle / EQ
4	4	VIDEO / 4	4
5	5	TAPE / 5	5
6	6	TUNER / 6	6
ANGLE	Angle	ANGLE / INFO	Info / Angle
7	7	AUX - HDD / 7	7
8	8	USB / 8	8
9	9	BLUETOOTH / 9	9
LANGUAGE	Language	LANG I/II / AUDIO	Audio / Lang I/II

Originale		Sostituto	
0	0	HDMI - SAT / 0	0
10+	10+	-/-- / GUIDE EPG	Guide / EPG / -/--
TIME	Time	TIMER / SLEEP	Sleep / Timer
SETUP	Setup	OPT-TOOLS / SETUP	Setup / OPT /
Up	Up		Up
TITLE	Title	TITLE / SOUND	Sound / Title
Left	Left		Left
Enter	Enter	OK	OK
Right	Right		Right
PBC	PBC	TOP MENU / D.MENU	D.Menu / Top
Down	Down		Down
MENU	Menu	HOME / MENU	Menu / Home
VOL-	Vol -	VOL -	Vol -
ZOOM	Zoom	SIZE / ZOOM	Zoom / Size
VOL+	Vol +	VOL +	Vol +
RETURN	Return	RETURN / BACK	Back / Return
USB	USB	SHIFT + USB / 8	Shift + 8

Originale	Sostituto	Originale	Sostituto
STEP Step	STEP-FREEZE Pause / Step / Freeze		
SLOW Slow	SHIFT + SLOW Shift + Play /		
PROGRAM Program	PROGRAM TV/RADIO TV/Radio /		
CLEAR Clear	CLEAR EXIT CANCEL Exit / Cancel / Clear		
MUTE Mute	DIMMER MUTE Mute / Dimmer		
DISPLAY Display	MEDIA DISPLAY Display / Media		
PREV Prev I<<	PRESET- I<< / Preset-		
NEXT Next >>I	PRESET+ >>I / Preset+		
REV Rev <<	TUNE- << / Tune-		
FWD Fwd >>	TUNE+ >> / Tune+		
V-MODE V-Mode	FORMAT PICTURE Picture / Format		
STOP Stop	HOLD Stop / Hold		
PLAY/PAUSE Play / Pause	SLOW Play / Slow		