| Originale | | Sostituto | | Originale | | Sostituto | |
|---|---|---|---|---|---|---|---|
| STANDBY | Standby | SHIFT + | Shift + Power | 2 | System Memory | SHIFT + DVD 2 | Shift + 2 |
| POWER | Power | | Power | 3 | System Memory | SHIFT + CD-STB 3 | Shift + 3 |
| MULTI | Multi | -/-- GUIDE EPG | Guide / EPG / -/-- | 4 | System Memory | SHIFT + VIDEO 4 | Shift + 4 |
| V-AUX | V-AUX | AUX-HDD 7 | 7 | TITLE BAND | Title | TITLE SOUND | Sound / Title |
| PHONO | Phono | SHIFT + | Shift + Sound / Title | MENU SRCH MODE | Menu | HOME MENU | Menu / Home |
| DOCK | Dock | SIZE ZOOM | Zoom / Size | VOLUME + | Vol + | + VOL | Vol + |
| BD HD DVD | BD/HD DVD | SHIFT + TAPE 5 | Shift + 5 | ▲ | Up | ▲ | Up |
| DVD | DVD | DVD 2 | 2 | ◀ | Left | ◀ | Left |
| CD | CD | CD-STB 3 | 3 | ENTER | Enter | OK | OK |
| MD CD-R | MD/CD-R | GOTO TEXT | Text / Goto | ▶ A-E | Right | ▶ | Right |
| CBL SAT | CBL/SAT | SHIFT + PROGRAM TV/RADIO | Shift + TV/Radio / Program | ▼ | Down | ▼ | Down |
| TV | TV | PROGRAM TV/RADIO | TV/Radio / | VOL − | Vol - | VOL − | Vol - |
| DVR | DVR | TOP MENU D.MENU | D.Menu / Top | RETURN MEMORY | Return | RETURN BACK | Back / Return |
| VCR | VCR | VIDEO 4 | 4 | PARAMETER DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| TUNER | Tuner | TUNER 6 | 6 | MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| USB | USB | USB 8 | 8 | CLASSICAL 1 | 1/Classical | TV 1 | 1 |
| 1 | System Memory | SHIFT + TV 1 | Shift + 1 | LIVE/CLUB 2 | 2/Live Club | SHIFT + MEDIA DISPLAY | Shift + Display / Media |

| Originale | | Sostituto | | Originale | Sostituto |
|---|---|---|---|---|---|
| ENTERTAIN 3 | 3/ Entertain | LIST SMART | Smart / List | | |
| MOVIE 4 | 4/ Movie | SHIFT + LIST SMART | Shift + Smart / List | | |
| STEREO 5 | 5/ Stereo | TAPE 5 | 5 | | |
| ENHANCER 6 | 6/ Enhancer | SHIFT + TUNER 6 | Shift + 6 | | |
| SUR. DECODE 7 | 7/ Sur. Decode | SHIFT + AUX - HDD 7 | Shift + 7 | | |
| STRAIGHT 8 | 8/ Straight | SHIFT + USB 8 | Shift + 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| EXTD SUR. +10 | +10/ EXTD Sur. | PC FAV MARKER | Fav / Marker / PC | | |
| PURE DIRECT ENT | ENT/ Pure Direct | SHIFT + OK | Shift + OK | | |
| INFO + | Info | ANGLE INFO | Info / Angle | | |
| LEVEL + | Level | OPT-TOOLS SETUP | Setup / OPT / | | |
| SLEEP MUTE | Sleep | TIMER SLEEP | Sleep / Timer | | |
| AUDIO SEL AUDIO | Audio/ Audio Se | LANG I/II AUDIO | Audio / Lang I/II | | |
| 3D DSP | 3D DSP | FORMAT PICTURE | Picture / Format | | |
| | | | | | |
| | | | | | |

| Originale | | Sostituto | | Originale | | Sostituto | |
|---|---|---|---|---|---|---|---|
| POWER | Power | | Power | | << | TUNE- | << / Tune- |
| TITLE | Title | TITLE SOUND | Sound / Title | EON | >> | TUNE+ | >> / Tune+ |
| MENU | Menu | HOME MENU | Menu / Home | MODE – PTY.S | I << | PRESET- | I << / Preset- |
| VOLUME + | Vol + | VOL + | Vol + | SEEK – START | >>I | PRESET+ | >>I / Preset+ |
| | Up | | Up | CLASSICAL 1 | 1 | TV 1 | 1 |
| | Left | | Left | LIVE/CLUB 2 | 2 | DVD 2 | 2 |
| ENTER | Enter | OK | OK | ENTERTAIN 3 | 3 | CD-STB 3 | 3 |
| A-E | Right | | Right | MOVIE 4 | 4 | VIDEO 4 | 4 |
| | Down | | Down | STEREO 5 | 5 | TAPE 5 | 5 |
| VOL – | Vol - | VOL – | Vol - | ENHANCER 6 | 6 | TUNER 6 | 6 |
| RETURN MEMORY | Return | RETURN BACK | Back / Return | SUR. DECODE 7 | 7 | AUX-HDD 7 | 7 |
| PARAMETER DISPLAY | Display | MEDIA DISPLAY | Display / Media | STRAIGHT 8 | 8 | USB 8 | 8 |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | 9 | 9 | BLUETOOTH 9 | 9 |
| REC | Rec | REC MODE | Rec / Rec Mode | 0 | 0 | HDMI-SAT 0 | 0 |
| | Pause | STEP-FREEZE | Pause / Step / Freeze | EXTD SUR. +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| | Play | SLOW | Play / Slow | PURE DIRECT ENT | ENT | SHIFT + OK | Shift + OK |
| | Stop | HOLD | Stop / Hold | AUDIO SEL AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |

| Originale | | Sostituto | | Originale | | Sostituto | |
|---|---|---|---|---|---|---|---|
| POWER | Power | | Power | | << | TUNE- | << / Tune- |
| TITLE BAND | Band | TOP MENU D.MENU | D. Menu / Top | EON | >> | TUNE+ | >> / Tune+ |
| MENU SRCH MODE | SRCH Mode | OPT-TOOLS SETUP | Setup / OPT / | MODE – PTY.S | I << | PRESET- | I << / Preset- |
| VOLUME + | Vol + | VOL + | Vol + | SEEK – START | >>I | PRESET+ | >>I / Preset+ |
| | UP Preset/CH+ | | Up | CLASSICAL 1 | 1 | TV 1 | 1 |
| | Left | | Left | LIVE/CLUB 2 | 2 | DVD 2 | 2 |
| ENTER | Enter | OK | OK | ENTERTAIN 3 | 3 | CD-STB 3 | 3 |
| A-E | Right/A-E | | Right | MOVIE 4 | 4 | VIDEO 4 | 4 |
| | Down | | Down | STEREO 5 | 5 | TAPE 5 | 5 |
| | Vol - | VOL – | Vol - | ENHANCER 6 | 6 | TUNER 6 | 6 |
| RETURN MEMORY | Memory | LIST SMART | Smart / List | SUR. DECODE 7 | 7 | AUX-HDD 7 | 7 |
| PARAMETER DISPLAY | Parameter | HOME MENU | Menu / Home | STRAIGHT 8 | 8 | USB 8 | 8 |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer | 9 | 9 | BLUETOOTH 9 | 9 |
| REC | Rec | REC MODE | Rec / Rec Mode | 0 | 0 | HDMI-BAT 0 | 0 |
| | Pause | STEP-FREEZE | Pause / Step / Freeze | EXTD SUR. +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| | Play | SLOW | Play / Slow | PURE DIRECT ENT | ENT | SHIFT + OK | Shift + OK |
| | Stop | HOLD | Stop / Hold | AUDIO SEL AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |

| Originale | | Sostituto | |
|---|---|---|---|
| POWER | Power | | Power |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| | Play | SLOW | Play / Slow |
| | Pause | STEP-FREEZE | Pause / Step / Freeze |
| | Stop | HOLD | Stop / Hold |
| REC | Rec | REC MODE | Rec / Rec Mode |
| | << | TUNE- | << / Tune- |
| | >> | TUNE+ | >> / Tune+ |
| | I<< | PRESET- | I<< / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| TITLE | Title | TITLE SOUND | Sound / Title |
| AUDIO SEL AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| MENU | Menu | HOME MENU | Menu / Home |
| | Up | | Up |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |

| Originale | | Sostituto | |
|---|---|---|---|
| | Down | | Down |
| RETURN MEMORY | Return | RETURN BACK | Back / Return |
| VOLUME + | Vol + | + VOL | Vol + |
| PURE DIRECT ENT | ENT | LIST SMART | Smart / List |
| | Vol - | VOL – | Vol - |
| PARAMETER DISPLAY | Display | MEDIA DISPLAY | Display / Media |
| CLASSICAL 1 | 1 | TV 1 | 1 |
| LIVE/CLUB 2 | 2 | DVD 2 | 2 |
| ENTERTAIN 3 | 3 | CD-STB 3 | 3 |
| MOVIE 4 | 4 | VIDEO 4 | 4 |
| STEREO 5 | 5 | TAPE 5 | 5 |
| ENHANCER 6 | 6 | TUNER 6 | 6 |
| SUR. DECODE 7 | 7 | AUX-HDD 7 | 7 |
| STRAIGHT 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| EXTD SUR. +10 | +10 | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI-SAT 0 | 0 |

| Originale | | Sostituto | |
|---|---|---|---|
| EXTD SUR. +10 | +10 Multi | PC FAV MARKER | Fav / Marker / PC |
| STANDBY | Power Multi | SHIFT + | Shift + Power |
| | Play Multi | SHIFT + SLOW | Shift + Play / |
| | Pause Multi | SHIFT + STEP-FREEZE | Shift + Pause / Step / |
| | Stop Multi | SHIFT + HOLD | Shift + Stop / |
| REC | Rec Multi | SHIFT + REC MODE | Shift + Rec / Rec Mode |
| | << Multi | SHIFT + TUNE- | Shift + << / |
| EON | >> Multi | SHIFT + TUNE+ | Shift + >> / |
| MODE – PTY | I << Multi | SHIFT + PRESET- | Shift + I << / Preset- |
| SEEK – START | >>I Multi | SHIFT + PRESET+ | Shift + >>I / Preset+ |
| TITLE BAND | Title Multi | SHIFT + TITLE SOUND | Shift + Sound / Title |
| AUDIO SEL AUDIO | Audio Multi | SHIFT + LANG I/II AUDIO | Shift + Audio / Lang I/II |
| MENU SRCH MODE | Menu Multi | SHIFT + HOME MENU | Shift + Menu / |
| | Up Multi | SHIFT + | Shift + Up |
| | Left Multi | SHIFT + | Shift + Left |
| ENTER | Enter Multi | SHIFT + OK | Shift + OK |
| A-E | Right Multi | SHIFT + | Shift + Right |

| Originale | | Sostituto | |
|---|---|---|---|
| | Down Multi | SHIFT + | Shift + Down |
| RETURN MEMORY | Return Multi | SHIFT + RETURN BACK | Shift + Back / Return |
| PURE DIRECT ENT | ENT Multi | SHIFT + LIST SMART | Shift + Smart / List |
| PARAMETER DISPLAY | Display Multi | SHIFT + MEDIA DISPLAY | Shift + Display / Media |
| CLASSICAL 1 | 1 Multi | SHIFT + TV 1 | Shift + 1 |
| LIVE/CLUB 2 | 2 Multi | SHIFT + DVD 2 | Shift + 2 |
| ENTERTAIN 3 | 3 Multi | SHIFT + CD - STB 3 | Shift + 3 |
| MOVIE 4 | 4 Multi | SHIFT + VIDEO 4 | Shift + 4 |
| STEREO 5 | 5 Multi | SHIFT + TAPE 5 | Shift + 5 |
| ENHANCER 6 | 6 Multi | SHIFT + TUNER 6 | Shift + 6 |
| SUR. DECODE 7 | 7 Multi | SHIFT + AUX - HDD 7 | Shift + 7 |
| STRAIGHT 8 | 8 Multi | SHIFT + USB 8 | Shift + 8 |
| 9 | 9 Multi | SHIFT + BLUETOOTH 9 | Shift + 9 |
| 0 | 0 Multi | SHIFT + HDMI - SAT 0 | Shift + 0 |