Originale	Sostituto	Originale	Sostituto
Power	Power	Pause	Pause / Step / Freeze
Mute	Mute / Dimmer	Exit	Exit / Cancel / Clear
1	1	SAT	Shift + 0
2	2	V-Mode	Display / Media
3	3	TV/AV	AV / Input / RDS
4	4	Sleep	Sleep / Timer
5	5	Up / PR+	CH+ / Page+
6	6	Up / PR+	Up
7	7	Left / Vol -	Left
8	8	Left / Vol -	Vol -
9	9	OK / List	OK
TV/Radio	TV/Radio /	OK / List	Smart / List
0	0	Right / Vol +	Vol +
EPG	Guide / EPG / -/--	Right / Vol +	Right
Fav	Fav / Marker / PC	Page-	Shift + CH- /
Menu	Menu / Home	Down / PR-	CH- / Page-
Info	Info / Angle	Down / PR-	Down

Originale	Sostituto	Originale	Sostituto
PAGE+ Page+	SHIFT + CH PAGE Shift + CH+ /		
FIND Red / Find	NETFLIX SEARCH Red / Netflix / Search		
V-FORMAT Green / V-Format	FORMAT PICTURE Picture / Format		
V-FORMAT Green / V-Format	APP REPEAT Green / APP / Repeat		
TXT Yellow / TXT	GOTO TEXT Text / Goto		
TXT Yellow / TXT	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue / Audio L/	LANG I/II AUDIO Audio / Lang I/II		
Blue / Audio L/	Prime Video RANDOM Blue / Prime Video / Random		
RECORD Record	REC MODE Rec / Rec Mode		
PLAY Play	SLOW Play / Slow		
STOP Stop	HOLD Stop / Hold		
SHIFT Shift	SURROUND Eject / Surround		
FAST << Fast	TUNE- << / Tune-		
FAST Fast >>	TUNE+ >> / Tune+		
< Slow	PRESET- I<< / Preset-		
SLOW Slow >	PRESET+ >>I / Preset+		