Originale		Sostituto	
STANDBY	Standby		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
REC LIST	Reclist	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II

Originale		Sostituto	
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TV/RADIO	TV / Radio	PROGRAM TV/ RADIO	TV/Radio /
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
VOL +	Vol +	VOL +	Vol +
	Rec	REC MODE	Rec / Rec Mode
CH +	CH +	CH PAGE +	CH+ / Page+
VOL -	Vol -	VOL -	Vol -
MEDIA	Media	SHIFT + MEDIA DISPLAY	Shift + Display / Media
MEDIA	Media	SURROUND	Eject / Surround
CH -	CH -	CH PAGE -	CH- / Page-

Originale		Sostituto	
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
PMODE	P. Mode	FORMAT PICTURE	Picture / Format
SMODE	S. Mode	TITLE SOUND	Sound / Title
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TEXT	Text	GOTO TEXT	Text / Goto
REVEAL	Reveal	TOP MENU D.MENU	D. Menu / Top
SUBPAGE	Subpage	OPT-TOOLS SETUP	Setup / OPT /
TIMESHIFT ⏯	Play/Pause / Timeshift	SLOW ▶	Play / Slow
TIMESHIFT ⏯	Play/Pause / Timeshift	STEP-FREEZE ⏸	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
INDEX	Index	ANGLE INFO	Info / Angle
SIZE	Size	SIZE ZOOM	Zoom / Size
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
	Red	NETFLIX SEARCH	Red / Netflix / Search

Originale		Sostituto	
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random