| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| OPEN/CLOSE | Open/Close | SURROUND | Eject / Surround |
| POWER | Power | | Power |
| TV/VCR | Tv/VCR | RDS AV INPUT | AV / Input / RDS |
| VCR | VCR | SHIFT + VIDEO 4 | Shift + 4 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| CLOCK/COUNTER | Clock Counter | ANGLE INFO | Info / Angle |
| PROGRAM | Program | PROGRAM TV/RADIO | TV/Radio / |
| ONE TOUCH REPEAT | One Touch | APP REPEAT | Green / APP / Repeat |
| INSTANT SKIP | Instant Skip | GOTO TEXT | Text / Goto |
| VCR MENU SETUP | Setup/VCR | OPT-TOOLS SETUP | Setup / OPT / |
| ZOOM | Zoom | SIZE ZOOM | Zoom / Size |
| SLOW | I > Slow | Prime Video RANDOM | Blue / Prime Video / Random |
| TOP MENU | Top Menu | TOP MENU D.MENU | D.Menu / Top |
| CH+ | Up | | Up |
| CH+ | CH+ | CH PAGE | CH+ / Page+ |
| DVD MENU | DVD Menu | HOME MENU | Menu / Home |
| SET- | Left/Set- | | Left |

| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| ENTER | Enter | OK | OK |
| SET+ | Right/Set+ | | Right |
| CANCEL CLEAR | Clear/Cancel | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| CH- | CH- | CH PAGE | CH- / Page- |
| CH- | Down | | Down |
| RETURN | Return | RETURN BACK | Back / Return |
| STOP | Stop | HOLD | Stop / Hold |
| PAUSE/STEP | Pause/Step | STEP-FREEZE | Pause / Step / Freeze |
| PLAY | Play | SLOW | Play / Slow |
| INDEX-SKIP- | I<< Skip/Index- | PRESET- | I<< / Preset- |
| REV | << | TUNE- | << / Tune- |
| FWD | >> | TUNE+ | >> / Tune+ |
| INDEX+SKIP+ | Skip | PRESET+ | >>I / Preset+ |
| REC/OTR | Rec/OTR | REC MODE | Rec / Rec Mode |
| TIMER REC | Timer Rec | TIMER SLEEP | Sleep / Timer |
| SP/LP PLAY MODE | Play | NETFLIX SEARCH | Red / Netflix / Search |
| A-B RPT | A-B RPT | YouTube REPEAT A-B | Yellow / YouTube / Repeat |

| Originalfernbedienung | | Ersatzfernbedienung | | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|---|---|
| 1 | 1 | TV 1 | 1 | | |
| 2 | 2 | DVD 2 | 2 | | |
| 3 | 3 | CD-STB 3 | 3 | | |
| CALL DISPLAY | Display/Call | MEDIA DISPLAY | Display / Media | | |
| 4 | 4 | VIDEO 4 | 4 | | |
| 5 | 5 | TAPE 5 | 5 | | |
| 6 | 6 | TUNER 6 | 6 | | |
| ZERO RETURN JUMP | Jump/Zero Return | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| 7 | 7 | AUX-HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| ●AUX 0 | 0/AUX | HDMI-SAT 0 | 0 | | |
| COUNTER RESET ANGLE | Camera/Angle/Counter Reset | FORMAT PICTURE | Picture / Format | | |
| ATR SUBTITLE | [...]/Subtitle/A | EQ SUBTITLE | Subtitle / EQ | | |
| AUDIO SELECT AUDIO | O))/Audio/Audio Select | LANG I/II AUDIO | Audio / Lang I/II | | |
| MARKER | Marker | PC FAV MARKER | Fav / Marker / PC | | |
| | | | | | |