Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power	Power	Sleep	Sleep / Timer
CBL/SAT	Shift + 0	Vol +	Vol +
DVD	Shift + 2	CH/Page-	CH- / Page-
TV Audio	Audio / Lang I/II	InstaPreuve	Smart / List
Blu-ray	Shift + 1	Mute	Mute / Dimmer
AUX1	Shift + 7	Vol -	Vol -
M-XPort	Fav / Marker / PC	Info	Info / Angle
Tuner	Shift + 6	Up	Up
Game	Shift + Fav / Marker / PC	Option	Shift + Setup / OPT / Tools
AUX2	Shift + 4	Option	D.Menu / Top
Phono	Shift + 9	Left	Left
iPod/USB	Shift + 8	Right	Right
Media Player	Shift + 5	Back	Back / Return
CD	Shift + 3	Down	Down
Network	Guide / EPG / -/--	Setup	Setup / OPT /
Internet Radio	Shift + Guide / EPG / -/--	Home	Menu / Home
CH/Page+	CH+ / Page+	Stop	Stop / Hold

Originalfernbedienung	Ersatzfernbedienung
Pause	Pause / Step / Freeze
Play	Play / Slow
I <</ Tune-	Shift + << /
I <</ Tune-	I << / Preset-
Tune+/ >>I	Shift + >> /
Tune+/ >>I	>>I / Preset+
<<	<< / Tune-
>>	>> / Tune+
Favorite Station	Shift + Red / Netflix /
Favorite Station	Shift + Green / APP /
Favorite Station	Shift + Yellow / YouTube /
Favorite Station	Shift + Blue / Prime
Red/ Movie	Red / Netflix / Search
Green/ Music	Green / APP / Repeat
Blue/ Game	Blue / Prime Video / Random
Yellow/ Pure	Yellow / YouTube / Repeat
1	1

Originalfernbedienung	Ersatzfernbedienung
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Enter	OK

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power	Power	Sleep	Sleep / Timer
CBL/SAT	SHIFT + HDMI-SAT 0 Shift + 0	Vol +	Vol +
DVD	SHIFT + DVD 2 Shift + 2	CH/Page-	CH- / Page-
Tv Audio	LANG I/II AUDIO Audio / Lang I/II	Mute	Mute / Dimmer
Blu-ray	SHIFT + TV 1 Shift + 1	Vol -	Vol -
AUX1	SHIFT + AUX-HDD 7 Shift + 7	Up	Up
M-XPort	PC FAV MARKER Fav / Marker / PC	Left	Left
Tuner	SHIFT + TUNER 6 Shift + 6	Right	Right
Game	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC	Back	Back / Return
AUX2	SHIFT + VIDEO 4 Shift + 4	Down	Down
Phono	SHIFT + BLUETOOTH 9 Shift + 9	Home	Menu / Home
iPod/USB	SHIFT + USB 8 Shift + 8	Stop	Stop / Hold
Media Player	SHIFT + TAPE 5 Shift + 5	Pause	Pause / Step / Freeze
CD	SHIFT + CD-STB 3 Shift + 3	Play	Play / Slow
Network	-/-- GUIDE EPG Guide / EPG / -/--	I <</ Tune-	SHIFT + TUNE- Shift + << /
Internet Radio	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--	I <</ Tune-	PRESET- I << / Preset-
CH/Page+	CH+ / Page+	>>I / Tune+	SHIFT + TUNE+ Shift + >> / Tune+

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
	>>I / Tune+	PRESET+	>>I / Preset+	ENTER	Enter	OK	OK
	<<	TUNE-	<< / Tune-				
	>>	TUNE+	>> / Tune+				
1	Favorite Station	NETFLIX SEARCH	Red / Netflix / Search				
2	Favorite Station	APP REPEAT	Green / APP / Repeat				
3	Favorite Station	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
4	Favorite Station	Prime Video RANDOM	Blue / Prime Video / Random				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD-STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX-HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
0	0	HDMI-SAT 0	0				

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power	SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
CBL/ SAT	CBL/ SAT	SHIFT + HDMI - SAT 0	Shift + 0	VOLUME	Vol +	VOL +	Vol +
DVD	DVD	SHIFT + DVD 2	Shift + 2		CH/ Page-	CH PAGE −	CH- / Page-
TV AUDIO	Tv Audio	LANG I/II AUDIO	Audio / Lang I/II	MUTE	Mute	DIMMER MUTE	Mute / Dimmer
Blu-ray	Blu-ray	SHIFT + TV 1	Shift + 1		Vol -	VOL −	Vol -
AUX1	AUX1	SHIFT + AUX - HDD 7	Shift + 7		Up		Up
M-XPort	M-XPort	PC FAV MARKER	Fav / Marker / PC		Left		Left
TUNER	Tuner	SHIFT + TUNER 6	Shift + 6		Right		Right
GAME	Game	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC	BACK	Back	RETURN BACK	Back / Return
AUX2	AUX2	SHIFT + VIDEO 4	Shift + 4		Down		Down
PHONO	Phono	SHIFT + BLUETOOTH 9	Shift + 9	HOME	Home	HOME MENU	Menu / Home
iPod/ USB	iPod/ USb	SHIFT + USB 8	Shift + 8		Stop	HOLD ■	Stop / Hold
MEDIA PLAYER	Media Player	SHIFT + TAPE 5	Shift + 5		Pause	STEP - FREEZE II	Pause / Step / Freeze
CD	CD	SHIFT + CD - STB 3	Shift + 3		Play	SLOW ▶	Play / Slow
NETWORK	Network	-/-- GUIDE EPG	Guide / EPG / -/--		I<</ Tune-	SHIFT + TUNE-	Shift + << /
INTERNET RADIO	Internet Radio	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--		I<</ Tune-	PRESET- ⏮	I<< / Preset-
CH / PAGE	CH/ Page+	CH PAGE +	CH+ / Page+		>>I / Tune+	SHIFT + TUNE+	Shift + >> / Tune+

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
	>>I / Tune+	PRESET+	>>I / Preset+	ENTER	Enter	OK	OK
	<<	TUNE-	<< / Tune-				
	>>	TUNE+	>> / Tune+				
1	Favorite Station	NETFLIX SEARCH	Red / Netflix / Search				
2	Favorite Station	APP REPEAT	Green / APP / Repeat				
3	Favorite Station	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
4	Favorite Station	Prime Video RANDOM	Blue / Prime Video / Random				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD-STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX-HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
0	0	HDMI-SAT 0	0				