Originalfernbedienung		Ersatzfernbedienung	
ON	ON		Power
STANDBY	Standby	SHIFT +	Shift + Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
BD/DVD	BD / DVD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL / SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	GAME	SHIFT + TAPE 5	Shift + 5
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TV/CD	TV/CD	SHIFT + CD - STB 3	Shift + 3
TV/CD	TV/CD	SHIFT + TV 1	Shift + 1
PHONO	PHONO	SHIFT + GUIDE EPG	Shift + Guide / EPG / -/--
PORT	PORT	PC FAV MARKER	Fav / Marker / PC
NET/USB	NET	SHIFT + BLUETOOTH 9	Shift + 9
NET/USB	USB	SHIFT + USB 8	Shift + 8
MUTING	Muting	DIMMER MUTE	Mute / Dimmer

Originalfernbedienung		Ersatzfernbedienung	
CH DISC	CH+	CH PAGE	CH+ / Page+
VOL	Vol +	VOL	Vol +
ALBUM	CH-	CH PAGE	CH- / Page-
VOL	Vol -	VOL	Vol -
GUIDE/TOP MENU SP LAYOUT	SP Layout	TOP MENU D.MENU	D. Menu / Top
	Up		Up
PREV CH/MENU VIDEO	Menu	HOME MENU	Menu / Home
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
HOME	Home	LIST SMART	Smart / List
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-

Originalfernbedienung		Ersatzfernbedienung	
	Play	SLOW	Play / Slow
	>>	TUNE+	>> / Tune+
	Pause / Play Rev	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie / TV	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat
THX PLAY MODE	Thx	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Originalfernbedienung		Ersatzfernbedienung	
+10 D.TUN DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
+10 D.TUN DIMMER	D. TUN	GOTO TEXT	Text / Goto
0	0	HDMI-SAT 0	0
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
On	Power	CH+ / Album+	CH+ / Page+
Standby	SHIFT + Power	Vol +	Vol +
Display	MEDIA DISPLAY / Media	CH- / Album	CH- / Page-
BD / DVD	SHIFT + DVD 2	Vol -	Vol -
VCR / DVR	SHIFT + VIDEO 4	Top Menu	TOP MENU D.MENU
CBL / SAT	SHIFT + HDMI - SAT 0	Up	Up
GAME	SHIFT + TAPE 5	Menu	HOME MENU
PC	SHIFT + PC FAV MARKER	Left / Playlist	Left
AUX	SHIFT + AUX - HDD 7	Enter	OK
TUNER	SHIFT + TUNER 6	Right / Playlist	Right
TV/CD	SHIFT + CD - STB 3	Setup	OPT-TOOLS SETUP
TV/CD	SHIFT + TV 1	Down	Down
PHONO	SHIFT + -/-- GUIDE EPG	Return	RETURN BACK
PORT	PC FAV MARKER / PC	Home	LIST SMART
NET	SHIFT + BLUETOOTH 9	I <<	PRESET- I << / Preset-
USB	SHIFT + USB 8	>>I	PRESET+ >>I / Preset+
Muting	DIMMER MUTE	<<	TUNE- << / Tune-

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
	Play	SLOW	Play / Slow	+10 D.TUN DIMMER	--/--- +10	GUIDE EPG	Guide / EPG / -/--
	>>	TUNE+	>> / Tune+	0	0	HDMI - SAT 0	0
	Pause / Play Rev	STEP - FREEZE	Pause / Step / Freeze	CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
	Stop	HOLD	Stop / Hold	CLR SLEEP	CLR	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MOVIE/TV SEARCH	Search	NETFLIX SEARCH	Red / Netflix / Search				
MUSIC REPEAT	Repeat	APP REPEAT	Green / APP / Repeat				
GAME RANDOM	Random	Prime Video RANDOM	Blue / Prime Video / Random				
THX PLAY MODE	Play Mode	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				

Originalfernbedienung		Ersatzfernbedienung	
ON	Power		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
BD/DVD	BD / DVD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL / SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	GAME	SHIFT + TAPE 5	Shift + 5
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TV/CD	TV / CD	SHIFT + CD - STB 3	Shift + 3
TV/CD	TV / CD	SHIFT + TV 1	Shift + 1
PHONO	PHONO	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PORT	PORT	PC FAV MARKER	Fav / Marker / PC
NET/USB	NET	SHIFT + BLUETOOTH 9	Shift + 9
NET/USB	USB	SHIFT + USB 8	Shift + 8
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CH DISC	CH+	CH PAGE	CH+ / Page+

Originalfernbedienung		Ersatzfernbedienung	
VOL	Vol +	VOL	Vol +
ALBUM	CH-	CH PAGE	CH- / Page-
VOL	Vol -	VOL	Vol -
GUIDE/TOP MENU SP LAYOUT	SP Layout	TOP MENU D.MENU	D. Menu / Top
	Up		Up
PREV CH/MENU VIDEO	Menu	HOME MENU	Menu / Home
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow

Originalfernbedienung		Ersatzfernbedienung	
	>>	TUNE+	>> / Tune+
	Pause	STEP-FREEZE	Pause / Step / Freeze
	Stop	HOLD	Stop / Hold
MOVIE/TV SEARCH	Movie / TV	NETFLIX SEARCH	Red / Netflix / Search
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat
THX PLAY MODE	Thx	Prime Video RANDOM	Blue / Prime Video / Random
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
+10 D.TUN DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer

Originalfernbedienung		Ersatzfernbedienung	
+10 D.TUN DIMMER	D.TUN	GOTO TEXT	Text / Goto
0	0	HDMI-SAT 0	0
CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer

Originalfernbedienung		Ersatzfernbedienung	
ON	Power		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
BD/DVD	BD / DVD	SHIFT + DVD 2	Shift + 2
VCR/DVR	VCR / DVR	SHIFT + VIDEO 4	Shift + 4
CBL/SAT	CBL / SAT	SHIFT + HDMI - SAT 0	Shift + 0
GAME	GAME	SHIFT + TAPE 5	Shift + 5
PC	PC	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
AUX	AUX	SHIFT + AUX - HDD 7	Shift + 7
TUNER	TUNER	SHIFT + TUNER 6	Shift + 6
TV/CD	TV / CD	SHIFT + CD - STB 3	Shift + 3
TV/CD	TV / CD	SHIFT + TV 1	Shift + 1
PHONO	PHONO	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
PORT	PORT	PC FAV MARKER	Fav / Marker / PC
NET/USB	NET	SHIFT + BLUETOOTH 9	Shift + 9
NET/USB	USB	SHIFT + USB 8	Shift + 8
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
CH DISC	CH+	CH PAGE	CH+ / Page+

Originalfernbedienung		Ersatzfernbedienung	
VOL	Vol +	VOL	Vol +
ALBUM	CH-	CH PAGE	CH- / Page-
VOL	Vol -	VOL	Vol -
GUIDE/TOP MENU SP LAYOUT	SP Layout	TOP MENU D.MENU	D. Menu / Top
	Up		Up
PREV CH/MENU VIDEO	Menu	HOME MENU	Menu / Home
PLAYLIST /CATEGORY	Left		Left
ENTER	Enter	OK	OK
PLAYLIST /CATEGORY	Right		Right
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
HOME	Home	SHIFT + HOME MENU	Shift + Menu /
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
	>>	TUNE+	>> / Tune+	+10 D.TUN DIMMER	D. TUN	GOTO TEXT	Text / Goto
	Pause	STEP - FREEZE	Pause / Step / Freeze	0	0	HDMI - SAT 0	0
	Stop	HOLD	Stop / Hold	CLR SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
MOVIE/TV SEARCH	Movie / TV	NETFLIX SEARCH	Red / Netflix / Search				
MUSIC REPEAT	Music	APP REPEAT	Green / APP / Repeat				
GAME RANDOM	Game	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
THX PLAY MODE	Thx	Prime Video RANDOM	Blue / Prime Video / Random				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
+10 D.TUN DIMMER	Dimmer	SHIFT +	DIMMER MUTE Shift + Mute / Dimmer				