Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
RECEIVER Power Receiver	Power	Up	Up
BD/DVD BD/DVD	SHIFT + DVD 2 Shift + 2	PLAYLIST Left Playlist	Left
CBL/SAT CBL/SAT	SHIFT + HDMI - SAT 0 Shift + 0	ENTER Enter	OK OK
GAME Game	SHIFT + BLUETOOTH 9 Shift + 9	PLAYLIST Right Playlis	Right
PC PC	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC	Q SETUP Q/ Setup	OPT-TOOLS SETUP Setup / OPT /
AUX AUX	SHIFT + AUX - HDD 7 Shift + 7	Down	Down
TUNER TUNER	SHIFT + TUNER 6 Shift + 6	RETURN Return	RETURN BACK Back / Return
TV/CD TV/CD	SHIFT + CD - STB 3 Shift + 3	AUDIO HOME Home/ Audio	LANG I/II AUDIO Audio / Lang I/II
PHONO Phono	SHIFT + VIDEO 4 Shift + 4	I<<	PRESET- I<< / Preset-
NET NET	SHIFT + -/-- GUIDE EPG Shift + Guide / EPG / -/--	<<	TUNE- << / Tune-
USB USB	SHIFT + USB 8 Shift + 8	>>	TUNE+ >> / Tune+
DISPLAY Display	MEDIA DISPLAY Display / Media	>>I	PRESET+ >>I / Preset+
MUTING Muting	DIMMER MUTE Mute / Dimmer	Pause	STEP - FREEZE Pause / Step / Freeze
CH DISC CH/ Disc/ Album	CH PAGE CH+ / Page+	Play	SLOW Play / Slow
VOL Vol +	VOL Vol +	Stop	HOLD Stop / Hold
ALBUM CH/ Disc/ Album	CH PAGE CH- / Page-	SEARCH MOVIE/TV A Movie/ Tv/ Search/	NETFLIX SEARCH Red / Netflix / Search
VOL Vol -	VOL Vol -	REPEAT MUSIC B Music/ Repeat/ B	APP REPEAT Green / APP / Repeat

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
RANDOM GAME C — Game/ Random/	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
MODE STEREO D — Stereo/ Mode/ D	Prime Video RANDOM — Blue / Prime Video / Random		
1 — 1	TV 1 — 1		
2 — 2	DVD 2 — 2		
3 — 3	CD - STB 3 — 3		
4 — 4	VIDEO 4 — 4		
5 — 5	TAPE 5 — 5		
6 — 6	TUNER 6 — 6		
7 — 7	AUX - HDD 7 — 7		
8 — 8	USB 8 — 8		
9 — 9	BLUETOOTH 9 — 9		
10 +10 D.TUN DIMMER — +10/ - - / - - - 10/ Dimmer/ D.Tun	-/-- GUIDE EPG — Guide / EPG / - / - -		
11 0 — 0/ 11	HDMI - SAT 0 — 0		
12 CLR SLEEP — CLR/ Sleep/ 12	PC FAV MARKER — Fav / Marker / PC		
12 CLR SLEEP — CLR/ Sleep/ 12	TIMER SLEEP — Sleep / Timer		
12 CLR SLEEP — CLR/ Sleep/ 12	CLEAR EXIT CANCEL — Exit / Cancel / Clear		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power BD/DVD		Power
	Play BD/DVD	SLOW	Play / Slow
	Pause BD/DVD	STEP-FREEZE	Pause / Step / Freeze
	Stop BD/DVD	HOLD	Stop / Hold
	<< BD/DVD	TUNE-	<< / Tune-
	>> BD/DVD	TUNE+	>> / Tune+
	I<< BD/DVD	PRESET-	I<< / Preset-
	>>I BD/DVD	PRESET+	>>I / Preset+
AUDIO HOME	Audio BD/DVD	LANG I/II AUDIO	Audio / Lang I/II
TOP MENU SP/GUIDE	Top Menu	TOP MENU D.MENU	D.Menu / Top
Q SETUP	Setup BD/DVD	OPT-TOOLS SETUP	Setup / OPT /
MENU PREV CH	Menu BD/DVD	HOME MENU	Menu / Home
	Up BD/DVD		Up
PLAYLIST	Left BD/DVD		Left
ENTER	Enter BD/DVD	OK	OK
PLAYLIST	Right BD/DVD		Right
12 CLR SLEEP	CLR/12 BD/DVD	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Originalfernbedienung		Ersatzfernbedienung	
	Down BD/DVD		Down
RETURN	Return BD/DVD	RETURN BACK	Back / Return
VOL	Vol + Receiver	VOL +	Vol +
BD/DVD	BD/DVD	LIST SMART	Smart / List
VOL	Vol - Receiver	VOL −	Vol -
CBL/SAT	CBL/SAT	MEDIA DISPLAY	Display / Media
1	1 BD/DVD	TV 1	1
2	2 BD/DVD	DVD 2	2
3	3 BD/DVD	CD-STB 3	3
4	4 BD/DVD	VIDEO 4	4
5	5 BD/DVD	TAPE 5	5
6	6 BD/DVD	TUNER 6	6
7	7 BD/DVD	AUX-HDD 7	7
8	8 BD/DVD	USB 8	8
9	9 BD/DVD	BLUETOOTH 9	9
10 +10 D.TUN DIMMER	+10/--/--10	-/-- GUIDE EPG	Guide / EPG / -/--
11 0	0/11 BD/DVD	HDMI-SAT 0	0

Originalfernbedienung	Ersatzfernbedienung
CLR/12 BD/DVD	Fav / Marker / PC
Search BD/DVD	Red / Netflix / Search
Repeat BD/DVD	Green / APP / Repeat
Stereo/Mode	Yellow / YouTube / Repeat
Random	Blue / Prime Video / Random
Power CBL/SAT	Shift + Power
Play CBL/SAT	Shift + Play /
Pause CBL/SAT	Shift + Pause / Step /
Stop CBL/SAT	Shift + Stop /
<< CBL/SAT	Shift + << /
>> CBL/SAT	Shift + >> /
Setup CBL/SAT	Shift + Setup / OPT / Tools
Menu/Prev CH CBL/SAT	Shift + Menu /
Up CBL/SAT	Shift + Up
Left CBL/SAT	Shift + Left
Enter CBL/SAT	Shift + OK
Right CBL/SAT	Shift + Right

Originalfernbedienung	Ersatzfernbedienung
Down CBL/SAT	Shift + Down
Return CBL/SAT	Shift + Back / Return
CH Disc/Album+ CBL/SAT	Shift + CH+ /
CH Disc/Album- CBL/SAT	Shift + CH- /
1 CBL/SAT	Shift + 1
2 CBL/SAT	Shift + 2
3 CBL/SAT	Shift + 3
4 CBL/SAT	Shift + 4
5 CBL/SAT	Shift + 5
6 CBL/SAT	Shift + 6
7 CBL/SAT	Shift + 7
8 CBL/SAT	Shift + 8
9 CBL/SAT	Shift + 9
Guide CBL/SAT	Shift + Guide / EPG / -/--
0/11 CBL/SAT	Shift + 0
Movie Tv/Search CBL/SAT	Shift + Red / Netflix /
Music/Repeat CBL/SAT	Shift + Green / APP / Repeat

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
RANDOM GAME C Game/ Random	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /		
MODE STEREO D Stereo/ Mode	SHIFT + Prime Video RANDOM Shift + Blue / Prime		

Originalfernbedienung	Ersatzfernbedienung
Power CD	Power
Play CD	Play / Slow
Pause CD	Pause / Step / Freeze
Stop CD	Stop / Hold
<< CD	<< / Tune-
>> CD	>> / Tune+
I<< CD	I<< / Preset-
>>I CD	>>I / Preset+
Audio CD	Audio / Lang I/II
Setup CD	Setup / OPT /
Up CD	Up
Left CD	Left
Enter CD	OK
Right CD	Right
Down CD	Down
Return CD	Back / Return
Vol + Receiver	Vol +

Originalfernbedienung	Ersatzfernbedienung
TV/CD	Smart / List
CH/Disc+ CD	CH+ / Page+
Vol - Receiver	Vol -
CH/Disc- CD	CH- / Page-
1 CD	1
2 CD	2
3 CD	3
4 CD	4
5 CD	5
6 CD	6
7 CD	7
8 CD	8
9 CD	9
+10/--/--10/D.Tun Dimmer CD	Guide / EPG / -/--
0/11 CD	0
CLR/Sleep/12	Fav / Marker / PC
Search CD	Red / Netflix / Search

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
REPEAT MUSIC B Repeat CD	APP REPEAT Green / APP / Repeat		
MODE STEREO D Mode CD	YouTube REPEAT A-B Yellow / YouTube / Repeat		
RANDOM GAME C Random CD	Prime Video RANDOM Blue / Prime Video / Random		

Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver Zone 2		Power
CH DISC	CH Disc/Album+ Zone 2	CH PAGE	CH+ / Page+
VOL	Vol + Zone 2	VOL	Vol +
ALBUM	CH Disc/Album Zone 2	CH PAGE	CH- / Page-
VOL	Vol - Zone 2	VOL	Vol -
	Up Zone 2		Up
PLAYLIST	Left Zone 2		Left
ENTER	Enter Zone 2	OK	OK
PLAYLIST	Right Zone 2		Right
SETUP	Setup Zone 2	OPT-TOOLS SETUP	Setup / OPT /
	Down Zone 2		Down
RETURN	Return Zone 2	RETURN BACK	Back / Return
AUDIO HOME	Audio Zone 2	LANG I/II AUDIO	Audio / Lang I/II
	I<< Zone 2	PRESET-	I<< / Preset-
	>>I Zone 2	PRESET+	>>I / Preset+
	<< Zone 2	TUNE-	<< / Tune-
	Play Zone 2	SLOW	Play / Slow

Originalfernbedienung		Ersatzfernbedienung	
	>> Zone 2	TUNE+	>> / Tune+
	Pause Zone 2	STEP-FREEZE	Pause / Step / Freeze
	Stop Zone 2	HOLD	Stop / Hold
SEARCH MOVIE/TV A	Movie Tv Zone	NETFLIX SEARCH	Red / Netflix / Search
REPEAT MUSIC B	Music Zone 2	APP REPEAT	Green / APP / Repeat
RANDOM GAME C	Game Zone 2	YouTube REPEAT A-B	Yellow / YouTube / Repeat
MODE STEREO D	Stereo Zone 2	Prime Video RANDOM	Blue / Prime Video / Random
1	1 Zone 2	TV 1	1
2	2 Zone 2	DVD 2	2
3	3 Zone 2	CD-STB 3	3
4	4 Zone 2	VIDEO 4	4
5	5 Zone 2	TAPE 5	5
6	6 Zone 2	TUNER 6	6
7	7 Zone 2	AUX-HDD 7	7
8	8 Zone 2	USB 8	8
9	9 Zone 2	BLUETOOTH 9	9
+10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer Zone 2	-/-- GUIDE EPG	Guide / EPG / -/--

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
0/11 Zone 2	0		
CLR/Sleep/12	Fav / Marker / PC		