Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
[+]	Zoom / Size	Left	Left
Power	Power	Right	Right
Source/[?]	AV / Input / RDS	Vol +	Vol +
>>	>> / Tune+	Vol -	Vol -
Red/Rec	Red / Netflix / Search	Mute	Mute / Dimmer
Green	Green / APP / Repeat	P+	CH+ / Page+
<<	<< / Tune-	P-	CH- / Page-
Yellow	Yellow / YouTube / Repeat	1	1
Stop	Stop / Hold	2	2
Blue	Blue / Prime Video / Random	3	3
Play	Play / Slow	4	4
Radio	TV/Radio /	5	5
[≡]	Text / Goto	6	6
[ ]	D.Menu / Top	7	7
Menu	Menu / Home	8	8
Up	Up	9	9
Down	Down	0	0

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
	[i+]	ANGLE INFO	Info / Angle		
	I-II	LANG I/II AUDIO	Audio / Lang I/II		
	[1|2]	EQ SUBTITLE	Subtitle / EQ		
	[:≡]	-/-- GUIDE EPG	Guide / EPG / -/--		
	[<>]	FORMAT PICTURE	Picture / Format		
	P<P	PC FAV MARKER	Fav / Marker / PC		
	♪/Smart	LIST SMART	Smart / List		
	[ ]/Smart	MEDIA DISPLAY	Display / Media		

Originalfernbedienung	Ersatzfernbedienung
Power SAT	SHIFT + Power
Power	Power
Source/[?]	AV / Input / RDS
Source SAT	SHIFT + AV / Input / RDS
>>	>> / Tune+
Red SAT	Red / Netflix / Search
<<	<< / Tune-
Green SAT	Green / APP / Repeat
Yellow SAT	Yellow / YouTube / Repeat
Stop	Stop / Hold
Play	Play / Slow
Blue SAT	Blue / Prime Video / Random
Radio	TV/Radio /
[≡]	Text / Goto
Up	Up
Up SAT	SHIFT + Up
Down	Down

Originalfernbedienung	Ersatzfernbedienung
Down SAT	SHIFT + Down
Left SAT	SHIFT + Left
Left	Left
Right SAT	SHIFT + Right
Right	Right
OK SAT	SHIFT + OK
OK	OK
[ ] SAT	SHIFT + Back / Return
[ ]	Back / Return
Menu SAT	D.Menu / Top
Menu	Menu / Home
Vol +	Vol +
Vol -	Vol -
Mute	Mute / Dimmer
P+ SAT	SHIFT + CH+ /
P+	CH+ / Page+
P- SAT	SHIFT + CH- / Page-

Originalfernbedienung		Ersatzfernbedienung	
P-		CH PAGE –	CH- / Page-
1	1 SAT	SHIFT + TV 1	Shift + 1
1	1	TV 1	1
2	2 SAT	SHIFT + DVD 2	Shift + 2
2	2	DVD 2	2
3	3 SAT	SHIFT + CD - STB 3	Shift + 3
3	3	CD - STB 3	3
4	4 SAT	SHIFT + VIDEO 4	Shift + 4
4	4	VIDEO 4	4
5	5 SAT	SHIFT + TAPE 5	Shift + 5
5	5	TAPE 5	5
6	6 SAT	SHIFT + TUNER 6	Shift + 6
6	6	TUNER 6	6
7	7 SAT	SHIFT + AUX - HDD 7	Shift + 7
7	7	AUX - HDD 7	7
8	8 SAT	SHIFT + USB 8	Shift + 8
8	8	USB 8	8

Originalfernbedienung		Ersatzfernbedienung	
9	9 SAT	SHIFT + BLUETOOTH 9	Shift + 9
9	9	BLUETOOTH 9	9
0	0 SAT	SHIFT + HDMI - SAT 0	Shift + 0
0	0	HDMI - SAT 0	0
[i+]		ANGLE INFO	Info / Angle
I-II	I - II	LANG I/II AUDIO	Audio / Lang I/II
[<>]		FORMAT PICTURE	Picture / Format
P<P		PC FAV MARKER	Fav / Marker / PC

Originalfernbedienung	Ersatzfernbedienung
Power	Power
>>	>> / Tune+
<<	<< / Tune-
Stop	Stop / Hold
Play	Play / Slow
Radio	TV/ Radio /
[ ]	Back / Return
Up	Up
Down	Down
Left	Left
Right	Right
Vol +	Vol +
Vol -	Vol -
Mute	Mute / Dimmer
P+	CH+ / Page+
P-	CH- / Page-
1	1

Originalfernbedienung	Ersatzfernbedienung
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
[i+]	Info / Angle
I-II	Audio / Lang I/II

Originalfernbedienung	Ersatzfernbedienung
Power AMP	SHIFT + Power: Shift + Power
Power	Power
Source/[?]	RDS AV INPUT: AV / Input / RDS
>>	TUNE+: >> / Tune+
>> AMP	PRESET+: >>I / Preset+
Red	NETFLIX SEARCH: Red / Netflix / Search
Rec	REC MODE: Rec / Rec Mode
<< AMP	PRESET-: I<< / Preset-
Green	APP REPEAT: Green / APP / Repeat
<<	TUNE-: << / Tune-
Yellow	YouTube REPEAT A-B: Yellow / YouTube / Repeat
Stop	HOLD: Stop / Hold
Blue	Prime Video RANDOM: Blue / Prime Video / Random
Play	SLOW: Play / Slow
Radio AMP	PROGRAM TV/RADIO: TV/Radio /
[≡] AMP	GOTO TEXT: Text / Goto
[ ]	RETURN BACK: Back / Return

Originalfernbedienung	Ersatzfernbedienung
Menu	HOME MENU: Menu / Home
Menu AMP	TOP MENU D.MENU: D.Menu / Top
Up AMP	SHIFT + ▲: Shift + Up
Up	▲: Up
Down	▼: Down
Down AMP	SHIFT + ▼: Shift + Down
Left	◀: Left
Left AMP	SHIFT + ◀: Shift + Left
Right	▶: Right
Right AMP	SHIFT + ▶: Shift + Right
OK	OK: OK
OK AMP	SHIFT + OK: Shift + OK
Vol + AMP	SHIFT + LIST SMART: Shift + Smart / List
Vol +	VOL +: Vol +
Vol -	VOL −: Vol -
Mute AMP	SHIFT + DIMMER MUTE: Shift + Mute / Dimmer
Mute	DIMMER MUTE: Mute / Dimmer

Originalfernbedienung		Ersatzfernbedienung	
P+	P+	CH+ / Page+	
P+ AMP	P+	Shift + CH+ /	
P- AMP	P-	Shift + CH- /	
P-	P-	CH- / Page-	
1 AMP	1	Shift + 1	
1	1	1	
2 AMP	2	Shift + 2	
2	2	2	
3 AMP	3	Shift + 3	
3	3	3	
4 AMP	4	Shift + 4	
4	4	4	
5 AMP	5	Shift + 5	
5	5	5	
6 AMP	6	Shift + 6	
6	6	6	
7 AMP	7	Shift + 7	

Originalfernbedienung		Ersatzfernbedienung	
7	7	7	
8 AMP	8	Shift + 8	
8	8	8	
9 AMP	9	Shift + 9	
9	9	9	
0 AMP	0	Shift + 0	
0	0	0	
[i+]		Info / Angle	
I-II		Audio / Lang I/II	
[1I2] AMP		Subtitle / EQ	
[+]		Zoom / Size	
[<>]		Picture / Format	
P<P		Fav / Marker / PC	
♪/Smart		Smart / List	
[ ]/Smart		Display / Media	