Originalfernbedienung		Ersatzfernbedienung	
POWER	Power	POWER	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
INFO	Info	ANGLE INFO	Info / Angle
0	0	HDMI - SAT 0	0
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
PAUSE	Pause	STEP - FREEZE II	Pause / Step / Freeze
MODE	Mode	FORMAT PICTURE	Picture / Format
PRE	PRE	RETURN BACK	Back / Return

Originalfernbedienung		Ersatzfernbedienung	
MENU	Menu	HOME MENU	Menu / Home
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
TV/RADIO	Tv/Radio	PROGRAM TV/ RADIO	TV/Radio /
	Down		Down
TV/SAT	Tv/SAT	LIST SMART	Smart / List
P-	P-	CH PAGE	CH- / Page-
UHF	UHF	MEDIA DISPLAY	Display / Media
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
P+	P+	CH PAGE	CH+ / Page+
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
TELETEXT Blue/Teletext	Prime Video RANDOM Blue / Prime Video / Random		
TELETEXT Blue/Teletext	GOTO TEXT Text / Goto		

Originalfernbedienung		Ersatzfernbedienung	
POWER	Power	POWER	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
INFO	Info	ANGLE INFO	Info / Angle
0	0	HDMI - SAT 0	0
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
PAUSE	Pause	STEP - FREEZE II	Pause / Step / Freeze
MODE	Mode	FORMAT PICTURE	Picture / Format
PRE	PRE	RETURN BACK	Back / Return

Originalfernbedienung		Ersatzfernbedienung	
MENU	Menu	HOME MENU	Menu / Home
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	OK
▶	Right	▶	Right
TV/RADIO	TV/Radio	PROGRAM TV/ RADIO	TV/Radio /
▼	Down	▼	Down
TV/SAT	TV/SAT	LIST SMART	Smart / List
P-	P-	CH PAGE −	CH- / Page-
P+	P+	+ CH PAGE	CH+ / Page+
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
TELETEXT	Blue / Teletex	Prime Video RANDOM	Blue / Prime Video / Random
TELETEXT	Blue / Teletex	GOTO TEXT	Text / Goto