Originalfernbedienung		Ersatzfernbedienung	
EJECT	Eject	SURROUND	Eject / Surround
POWER	Power		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
SCROLL	Scroll	EQ SUBTITLE	Subtitle / EQ
CONTINUE A	Continue Play Mode/A	NETFLIX SEARCH	Red / Netflix / Search
SHUFFLE B	Shuffle Play	TITLE SOUND	Sound / Title
PROGRAM C	Program/C	PROGRAM TV/RADIO	TV/Radio /
D	D	Prime Video RANDOM	Blue / Prime Video / Random
E	E	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8

Originalfernbedienung		Ersatzfernbedienung	
9	9	BLUETOOTH 9	9
10	10	HDMI-SAT 0	0
11	11	-/-- GUIDE EPG	Guide / EPG / -/--
12	12	PC FAV MARKER	Fav / Marker / PC
13	13	SHIFT + TV 1	Shift + 1
14	14	SHIFT + DVD 2	Shift + 2
15	15	SHIFT + CD-STB 3	Shift + 3
16	16	SHIFT + VIDEO 4	Shift + 4
17	17	SHIFT + TAPE 5	Shift + 5
18	18	SHIFT + TUNER 6	Shift + 6
19	19	SHIFT + AUX-HDD 7	Shift + 7
20	20	SHIFT + USB 8	Shift + 8
21	21	SHIFT + BLUETOOTH 9	Shift + 9
22	22	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
23	23	SHIFT + HDMI-SAT 0	Shift + 0
24	24	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
25	25	SHIFT + ANGLE INFO	Shift + Info / Angle

Originalfernbedienung		Ersatzfernbedienung	
>25	>25	TOP MENU / D.MENU	D.Menu / Top
REPEAT	Repeat	APP / REPEAT	Green / APP / Repeat
A-B	A-B	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
A.SPACE	A.Space	SIZE / ZOOM	Zoom / Size
M.SCAN	M.Scan	FORMAT / PICTURE	Picture / Format
NAME	Name Write	HOME / MENU	Menu / Home
CHAR	Char Write	ANGLE / INFO	Info / Angle
NUM	Num Write	LANG I/II / AUDIO	Audio / Lang I/II
CLEAR	Clear	CLEAR / EXIT / CANCEL	Exit / Cancel / Clear
▷	Play	SLOW ▶	Play / Slow
❚❚	Pause	STEP - FREEZE ❚❚	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
●	Rec	REC MODE ●	Rec / Rec Mode
REC PAUSE	Rec Pause	SHIFT + STEP - FREEZE ❚❚	Shift + Pause / Step /
◀◀	<<	TUNE- ◀◀	<< / Tune-

Originalfernbedienung		Ersatzfernbedienung	
▶▶	>>	TUNE+ ▶▶	>> / Tune+
CD-SYNC	CD-Sync	RDS / AV INPUT	AV / Input / RDS
REC-IT	Rec-IT	SHIFT + REC MODE ●	Shift + Rec / Rec Mode
ERASE	Erase	▲	Up
DIVIDE	Divide	◀	Left
COMBINE	Combine	▼	Down
MOVE	Move	▶	Right
ENTER	Enter	OK	OK
CANCEL	Cancel	SHIFT + CLEAR / EXIT / CANCEL	Shift + Exit / Cancel / Clear
UNDO	Undo	DIMMER / MUTE	Mute / Dimmer

Originalfernbedienung		Ersatzfernbedienung	
EJECT	Eject	SURROUND	Eject / Surround
POWER	Power		Power
DISPLAY	Display	MEDIA DISPLAY	Display / Media
CONTINUE A	Continue Play Mode/A	NETFLIX SEARCH	Red / Netflix / Search
SHUFFLE B	Shuffle Play	TITLE SOUND	Sound / Title
PROGRAM C	Program/C	PROGRAM TV/RADIO	TV/Radio /
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
10	10	HDMI - SAT 0	0
11	11	-/-- GUIDE EPG	Guide / EPG / -/--

Originalfernbedienung		Ersatzfernbedienung	
12	12	PC FAV MARKER	Fav / Marker / PC
13	13	SHIFT + TV 1	Shift + 1
14	14	SHIFT + DVD 2	Shift + 2
15	15	SHIFT + CD - STB 3	Shift + 3
16	16	SHIFT + VIDEO 4	Shift + 4
17	17	SHIFT + TAPE 5	Shift + 5
18	18	SHIFT + TUNER 6	Shift + 6
19	19	SHIFT + AUX - HDD 7	Shift + 7
20	20	SHIFT + USB 8	Shift + 8
21	21	SHIFT + BLUETOOTH 9	Shift + 9
22	22	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
23	23	SHIFT + HDMI - SAT 0	Shift + 0
24	24	SHIFT + PC FAV MARKER	Shift + Fav / Marker / PC
25	25	ANGLE INFO	Info / Angle
>25	>25	TOP MENU D.MENU	D.Menu / Top
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Originalfernbedienung		Ersatzfernbedienung	
A.SPACE	A.Space	SIZE ZOOM	Zoom / Size
M.SCAN	M.Scan	FORMAT PICTURE	Picture / Format
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
LOOP	Loop	RETURN BACK	Back / Return
▷	Play	SLOW ▶	Play / Slow
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
■	Stop	HOLD ■	Stop / Hold
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
●	Rec	REC MODE ●	Rec / Rec Mode
REC PAUSE	Rec Pause	SHIFT + STEP-FREEZE ❚❚	Shift + Pause / Step /
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
CD-SYNC	CD-Sync	RDS AV INPUT	AV / Input / RDS
REC-IT	Rec-IT	SHIFT + REC MODE ●	Shift + Rec / Rec Mode

Originalfernbedienung	Ersatzfernbedienung