Originalfernbedienung	Ersatzfernbedienung
Power	Power
Mute	Mute / Dimmer
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
TV/Radio	TV/Radio /
0	0
<- PR	Back / Return
TV/AV	AV / Input / RDS
Fav	Fav / Marker / PC
Sleep	Sleep / Timer

Originalfernbedienung	Ersatzfernbedienung
Menu	Menu / Home
Pause	Pause / Step / Freeze
Exit	Exit / Cancel / Clear
SAT	Shift + 0
Page+	Shift + CH+ /
Info	Info / Angle
Page-	Shift + CH- /
Up / PR+	CH+ / Page+
Up / PR+	Up
Left / Vol -	Left
Left / Vol -	Vol -
OK / List	OK
OK / List	Smart / List
Right / Vol +	Vol +
Right / Vol +	Right
Down / PR-	CH- / Page-
Down / PR-	Down

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
FIND Red / Find	NETFLIX SEARCH Red / Netflix / Search		
V-FORMAT Green / V-Format	FORMAT PICTURE Picture / Format		
V-FORMAT Green / V-Format	APP REPEAT Green / APP / Repeat		
TXT Yellow / TXT	GOTO TEXT Text / Goto		
TXT Yellow / TXT	YouTube REPEAT A-B Yellow / YouTube / Repeat		
Blue / Audio L/	LANG I/II AUDIO Audio / Lang I/II		
Blue / Audio L/	Prime Video RANDOM Blue / Prime Video / Random		
RECORD Record	REC MODE Rec / Rec Mode		
PLAY Play	SLOW Play / Slow		
STOP Stop	HOLD Stop / Hold		
SHIFT Shift	SURROUND Eject / Surround		
<< Fast	TUNE- << / Tune-		
Fast >>	TUNE+ >> / Tune+		
< Slow	PRESET- I<< / Preset-		
Slow >	PRESET+ >>I / Preset+		