Mandis shop

Sony RM-DX50

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
CONTINUE	Continue	LIST SMART	Smart / List	DISPLAY ON/OFF	Display On/Off	MEDIA DISPLAY	Display / Media
SHUFFLE	Shuffle	Prime Video RANDOM	Blue / Prime Video / Random	REPEAT CLEAR	Repeat	APP REPEAT	Green / APP / Repeat
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /	A-B	A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
1	1	TV 1	1	FADER	Fader	DIMMER MUTE	Mute / Dimmer
2	2	DVD 2	2	▷	Play	SLOW ▶	Play / Slow
3	3	CD-STB 3	3	❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze
4	4	VIDEO 4	4	■	Stop	HOLD ■	Stop / Hold
5	5	TAPE 5	5	AMS ⏮	I<<	PRESET- ⏮	I<< / Preset-
6	6	TUNER 6	6	AMS ⏭	>>I	PRESET+ ⏭	>>I / Preset+
7	7	AUX-HDD 7	7	LINE OUT LEVEL	Line Out Level -	+ CH PAGE	CH+ / Page+
8	8	USB 8	8	◀◀	<<	TUNE- ◀◀	<< / Tune-
9	9	BLUETOOTH 9	9	▶▶	>>	TUNE+ ▶▶	>> / Tune+
>10	>10	-/-- GUIDE EPG	Guide / EPG / -/--		Line Out Level	CH PAGE −	CH- / Page-
10	10	HDMI-SAT 0	0				
CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
CHECK	Check	RETURN BACK	Back / Return				
TIME	Time	TIMER SLEEP	Sleep / Timer				

https://remotecontrols.de/Sony/1088-676-ersatzfernbedienung-fur-Sony-RM-DX50-143202.html