Originalfernbedienung		Ersatzfernbedienung	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
POWER	Power		Power
CBL/SAT	CBL/SAT	TV 1	1
MEDIA PLAYER	Media Player	DVD 2	2
Blu-ray	Blu-ray	CD - STB 3	3
GAME	Game	VIDEO 4	4
AUX1	AUX1	-/-- GUIDE EPG	Guide / EPG / -/--
AUX2	AUX2	HDMI - SAT 0	0
TV AUDIO	Tv Audio	AUX - HDD 7	7
PHONO	Phono	TAPE 5	5
TUNER	Tuner	TUNER 6	6
USB	USB	USB 8	8
Bluetooth	Bluetooth	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	PC FAV MARKER	Fav / Marker / PC
	.:l:.	LIST SMART	Smart / List
CH / PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
VOLUME	Volume+	+ VOL	Vol +

Originalfernbedienung		Ersatzfernbedienung	
CH / PAGE	CH/Page-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Volume-	VOL –	Vol -
INFO	Info	ANGLE INFO	Info / Angle
OPTION	Option	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
TUNE –	I<<Tune-	PRESET-	I<< / Preset-
►/II	Play	SLOW ►	Play / Slow
►/II	Pause	STEP - FREEZE II	Pause / Step / Freeze
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+
1	Quick Select 1	NETFLIX SEARCH	Red / Netflix / Search

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
2	Quick Select 2	APP / REPEAT	Green / APP / Repeat				
3	Quick Select 3	YouTube / REPEAT A-B	Yellow / YouTube / Repeat				
4	Quick Select 4	Prime Video / RANDOM	Blue / Prime Video / Random				
MOVIE	Movie	EQ / SUBTITLE	Subtitle / EQ				
MUSIC	Music	TITLE / SOUND	Sound / Title				
GAME	Game	FORMAT / PICTURE	Picture / Format				
PURE	Pure	SIZE / ZOOM	Zoom / Size				

Originalfernbedienung		Ersatzfernbedienung	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
POWER	Power		Power
CBL/SAT	CBL/SAT	TV 1	1
MEDIA PLAYER	Media Player	DVD 2	2
Blu-ray	Blu-ray	CD - STB 3	3
GAME	Game	VIDEO 4	4
AUX1	AUX1	-/-- GUIDE EPG	Guide / EPG / -/--
AUX2	AUX2	HDMI - SAT 0	0
TV AUDIO	Tv Audio	AUX - HDD 7	7
PHONO	Phono	TAPE 5	5
TUNER	Tuner	TUNER 6	6
USB	USB	USB 8	8
Bluetooth	Bluetooth	BLUETOOTH 9	9
INTERNET RADIO	Internet Radio	PC FAV MARKER	Fav / Marker / PC
	.:l:.	LIST SMART	Smart / List
CH / PAGE	CH/Page+	+ CH PAGE	CH+ / Page+
VOLUME	Volume+	+ VOL	Vol +

Originalfernbedienung		Ersatzfernbedienung	
CH / PAGE	CH/Page-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
VOLUME	Volume-	VOL –	Vol -
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
TUNE –	I<<</Tune-	PRESET-	I<< / Preset-
►/II	Play	SLOW	Play / Slow
►/II	Pause	STEP - FREEZE II	Pause / Step / Freeze
TUNE +	>>I / Tune+	PRESET+	>>I / Preset+
1	Quick Select 1	NETFLIX SEARCH	Red / Netflix / Search
2	Quick Select 2	APP REPEAT	Green / APP / Repeat
3	Quick Select 3	YouTube REPEAT A-B	Yellow / YouTube / Repeat
4	Quick Select 4	Prime Video RANDOM	Blue / Prime Video / Random