Originalfernbedienung	Ersatzfernbedienung
Power	Power
Red/ Sound↑	Red / Netflix / Search
Red/ Sound↑	Sound / Title
Green/ Picture/ ↓	Green / APP / Repeat
Green/ Picture/ ↓	Picture / Format
Yellow/ Feature	Yellow / YouTube / Repeat
Blue/ Install	Blue / Prime Video / Random
[≡]	Text / Goto
[≡0]	Play / Slow
[≡+]	Stop / Hold
[≡x] / [· ·]	Pause / Step / Freeze
[/≡] / [*]	Rec / Rec Mode
[+] ([≡♦] / Wide	Zoom / Size
[≡?] / PC	Fav / Marker / PC
[≡i] / Guide	Guide / EPG / -/--
1	1
2	2

Originalfernbedienung	Ersatzfernbedienung
3	3
4	4
5	5
6	6
7	7
8	8
9	9
P<P	Display / Media
0	0
-/-- EXIT	Shift + Guide / EPG / -/--
Vol -	Vol -
Vol +	Vol +
Mute	Mute / Dimmer
P-	CH- / Page-
P+	CH+ / Page+
[i] / Info	Info / Angle
TV/ DTV	TV/ Radio / Program

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
AV	AV / Input / RDS		
I - II	Audio / Lang I/II		
PP	Back / Return		
Up	Up		
Left	Left		
OK/Select	OK		
Right	Right		
M	Menu / Home		
Down	Down		