Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power	Power	Left	Left
Mute	Mute / Dimmer	OK	OK
1	1	Right	Right
2	2	Down	Down
3	3	Back	Back / Return
4	4	Menu	D. Menu / Top
5	5	Netflix	Shift + Red / Netflix /
6	6	YouTube	Shift + Yellow / YouTube /
7	7	prime video	Shift + Blue / Prime
8	8	Google Play	Shift + Green / APP /
9	9	Vol +	Vol +
Source	AV / Input / RDS	Grid	Smart / List
0	0	P+	CH+ / Page+
.	Shift + Guide / EPG / -/--	Vol -	Vol -
☼	Setup / OPT /	Home	Menu / Home
Up	Up	P-	CH- / Page-
Exit	Exit / Cancel / Clear	Info	Info / Angle

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
USB	USB	SHIFT + USB 8	Shift + 8		
MTS	MTS	MEDIA DISPLAY	Display / Media		
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
▶	Play	SLOW ▶	Play / Slow		
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze		
■	Stop	HOLD ■	Stop / Hold		
●	Rec	REC MODE ●	Rec / Rec Mode		
◀◀	<<	TUNE- ◀◀	<< / Tune-		
❙◀◀	I <<	PRESET- ❙◀◀	I << / Preset-		
▶▶❙	>>I	PRESET+ ▶▶❙	>>I / Preset+		
▶▶	>>	TUNE+ ▶▶	>> / Tune+		
●	Red	NETFLIX SEARCH	Red / Netflix / Search		
●	Green	APP REPEAT	Green / APP / Repeat		
●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
●	Blue	Prime Video RANDOM	Blue / Prime Video / Random		