Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver		Power
ENTER	Enter Receiver	OK	Ok
	Up Receiver		Up
	Down Receiver		Down
	Right Receiver		Right
	Left Receiver		Left
RETURN	Return Receiver	RETURN BACK	Back
Q SETUP	Q/Setup Receiver	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
PLAY	Play Receiver	PLAY MODE	Play
	I<< Receiver		I<<
	>>I Receiver		>>I
	<< Receiver		<<
	>> Receiver		>>
	Pause Receiver		Pause
	Stop Receiver		Stop
1	1 Receiver	1	1

Originalfernbedienung		Ersatzfernbedienung	
2	2 Receiver	2	2
3	3 Receiver	3	3
4	4 Receiver	4	4
5	5 Receiver	5	5
6	6 Receiver	6	6
7	7 Receiver	7	7
8	8 Receiver	8	8
9	9 Receiver	9	9
11 0	0/11 Receiver	0	0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10/Dimmer/D.Tun Receive	SHIFT + -/-- GUIDE	Shift + Guide
12 CLR SLEEP	CLR/Sleep/12 Receiver	FAV PRE-CH	Pre Ch
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Receiver	B	Green
RANDOM GAME C	Game/Yellow/Random Receiver	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Receiver	D	Blue
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL –	Vol -

Originalfernbedienung		Ersatzfernbedienung	
CH Disc/Album+ Receiver		+ CH	Ch +
CH Disc/Album- Receiver		CH −	Ch -
Power Tv		SHIFT +	Shift + Power
Input Tv		TIMER AV	AV
CH+ Tv		SHIFT + + CH	Shift + Ch +
CH- Tv		SHIFT + CH −	Shift + Ch -
Up Tv		SHIFT +	Shift + Up
Enter Tv		SHIFT + OK	Shift + Ok
Down Tv		SHIFT +	Shift + Down
Right Tv		SHIFT +	Shift + Right
Left Tv		SHIFT +	Shift + Left
Menu/Prev CH		TOP MENU MENU	Menu
Top Menu/Guide		SHIFT + TOP MENU MENU	Shift + Menu
Return Tv		SHIFT + RETURN BACK	Shift + Back
Q/Setup Tv		SHIFT + HOME SMART	Shift + Smart
Red Tv		SETTINGS OPT	Options
Green Tv		SOUND DUAL	Dual

Originalfernbedienung		Ersatzfernbedienung	
Yellow Tv		AD SUBT	Subt
Blue Tv		SEARCH TV/R	TV/R
1 Tv		SHIFT + 1	Shift + 1
2 Tv		SHIFT + 2	Shift + 2
3 Tv		SHIFT + 3	Shift + 3
4 Tv		SHIFT + 4	Shift + 4
5 Tv		SHIFT + 5	Shift + 5
6 Tv		SHIFT + 6	Shift + 6
7 Tv		SHIFT + 7	Shift + 7
8 Tv		SHIFT + 8	Shift + 8
9 Tv		SHIFT + 9	Shift + 9
0/11 Tv		SHIFT + 0	Shift + 0
+10/--/--10 Tv		-/-- GUIDE	Guide
CLR/Sleep/12		SHIFT + FAV PRE-CH	Shift + Pre Ch
Vol + Tv		SHIFT + SOUND DUAL	Shift + Dual
Vol - Tv		SHIFT + SETTINGS OPT	Shift + Options
AUX		REPEAT TEXT	Text

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
TV/CD TV/ CD	PICTURE FORMAT For mat		
CBL/SAT CBL/ SAT	ECO 3D 3D		
FM FM	SHIFT + AD SUBT Shi f t + Subt		
NET NET	SHIFT + APP MEDIA Shi f t + Medi a		
PC PC	SHIFT + SEARCH TV/R Shi f t + TV/ R		
BD/DVD BD/ DVD	SHIFT + REPEAT TEXT Shi f t + Text		
USB USB	SHIFT + TIMER AV Shi f t + AV		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Q/Setup	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
PLAY	Play BD/DVD	PLAY MODE	Play
	Pause BD/DVD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat BD/DVD	B	Green
RANDOM GAME C	Game/Yellow/Random BD/DVD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
--/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tuner Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Originalfernbedienung	Ersatzfernbedienung
CBL/SAT	Text
Vol + Receiver	Vol +
Vol - Receiver	Vol -
Power CBL/SAT	Shift + Power
CH Disc/Album+ CBL/SAT	Ch +
CH Disc/Album- CBL/SAT	Ch -
Menu/Prev CH CBL/SAT	Shift + Menu
Top Menu/Guide CBL/SAT	Shift + Options
Return CBL/SAT	Shift + Back
Q/Setup	Shift + Smart
Up CBL/SAT	Shift + Up
Enter CBL/SAT	Shift + Ok
Down CBL/SAT	Shift + Down
Right CBL/SAT	Shift + Right
Left CBL/SAT	Shift + Left
Pause CBL/SAT	Shift + Pause
Stop CBL/SAT	Shift + Stop

Originalfernbedienung	Ersatzfernbedienung
<< CBL/SAT	Shift + Ch -
>> CBL/SAT	Shift + Ch +
Play CBL/SAT	3D
Movie Tv/Red/Search	Dual
Music/Green/Repeat CBL/SAT	Subt
Game/Yellow/Random CBL/SAT	AV
Stereo/Blue/Mode CBL/SAT	Format
1 CBL/SAT	Shift + 1
2 CBL/SAT	Shift + 2
3 CBL/SAT	Shift + 3
4 CBL/SAT	Shift + 4
5 CBL/SAT	Shift + 5
6 CBL/SAT	Shift + 6
7 CBL/SAT	Shift + 7
8 CBL/SAT	Shift + 8
9 CBL/SAT	Shift + 9
0/11 CBL/SAT	Shift + 0

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
BD/DVD BD/ DVD	SEARCH TV/R TV/ R		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power TV/CD		Power
CH DISC +	CH/Disc+ TV/CD	CH +	Ch +
ALBUM −	CH/Disc TV/CD	CH −	Ch -
RETURN	Return TV/CD	RETURN BACK	Back
Q SETUP	Q/Setup TV/CD	HOME SMART	Smart
AUDIO HOME	Home/Audio	APP MEDIA	Media
	Up TV/CD		Up
	Down TV/CD		Down
	Right TV/CD		Right
	Left TV/CD		Left
ENTER	Enter TV/CD	OK	Ok
⏮	I<< TV/CD	⏮	I<<
⏭	>>I TV/CD	⏭	>>I
◀◀	<< TV/CD	◀◀	<<
▶▶	>> TV/CD	▶▶	>>
PLAY	Play TV/CD	PLAY MODE ▶	Play
⏸	Pause TV/CD	⏸	Pause

Originalfernbedienung		Ersatzfernbedienung	
■	Stop TV/CD	■	Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat TV/CD	B	Green
RANDOM GAME C	Game/Yellow/Random TV/CD	C	Yellow
MODE STEREO D	Stereo/Blue/Mode TV/CD	D	Blue
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9
11 0	0/11 TV/CD	0	0
-/-- 10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer TV/CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

TV/CD

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
VOL Vol + Recei ver	+ VOL Vol +		
VOL Vol - Recei ver	VOL – Vol -		
TV/CD TV/ CD	SEARCH TV/R TV/ R		

Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	VOL +	Vol +
VOL	Vol - Zone 2	VOL −	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH +	Ch +
ALBUM	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
	Right Zone 2		Right
	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
Q SETUP	Q/Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Home/Audio Zone	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
PLAY	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Originalfernbedienung		Ersatzfernbedienung	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Red/Search	A	Red
REPEAT MUSIC B	Music/Green/Repeat Zone 2	B	Green
RANDOM GAME C	Game/Yellow/Random Zone 2	C	Yellow
MODE STEREO D	Stereo/Blue/Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
0 11	0/11 Zone 2	0	0

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
+10/ - - / - - 10/ D. Tu Di mmer Zone 2	Gui de		
CLR/ Sl eep/ 12	Pr e Ch		