Originalfernbedienung		Ersatzfernbedienung	
MUTING	Muting Receiver	MUTE	Mute
RECEIVER	Power Receiver		Power
DISPLAY	Display	DISPLAY INFO	Info
ENTER	Enter Receiver	OK	Ok
	Up Receiver		Up
	Down Receiver		Down
PLAYLIST	Right Receiver		Right
PLAYLIST	Left Receiver		Left
RETURN	Return Receiver	RETURN BACK	Back
SETUP	Setup Receiver	HOME SMART	Smart
AUDIO HOME	Audio/Home	APP MEDIA	Media
	Play Receiver	PLAY MODE	Play
	I<< Receiver		I<<
	>>I Receiver		>>I
	<< Receiver		<<
	>> Receiver		>>
	Pause/Play reverse Receiver		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop Receiver		Stop
1	1 Receiver	1	1
2	2 Receiver	2	2
3	3 Receiver	3	3
4	4 Receiver	4	4
5	5 Receiver	5	5
6	6 Receiver	6	6
7	7 Receiver	7	7
8	8 Receiver	8	8
9	9 Receiver	9	9
0 11	0/11 Receiver	0	0
10 +10 D.TUN DIMMER	+10/---/---10/Dimer/D.Tun Receive	SHIFT + GUIDE	Shift + Guide
12 CLR SLEEP	CLR/Sleep/12 Receiver	FAV PRE-CH	Pre Ch
SEARCH MOVIE/TV A	Movie Tv/Search Receiver	A	Red
REPEAT MUSIC B	Music/Repeat Receiver	B	Green
RANDOM GAME C	Game/Random Receiver	C	Yellow
MODE THX D	THX/Play Mode Receiver	D	Blue

Originalfernbedienung		Ersatzfernbedienung	
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL –	Vol -
CH DISC	CH/Disc/Album+ Receiver	+ CH	Ch +
ALBUM	CH/Disc/Album Receiver	CH –	Ch -
TV	Power Tv	SHIFT +	Shift + Power
TV INPUT	Input Tv	TIMER AV	AV
CH DISC	CH+ Tv	SHIFT + + CH	Shift + Ch +
ALBUM	CH- Tv	SHIFT + CH –	Shift + Ch -
	Up Tv	SHIFT +	Shift + Up
ENTER	Enter Tv	SHIFT + OK	Shift + Ok
	Down Tv	SHIFT +	Shift + Down
PLAYLIST	Right Tv	SHIFT +	Shift + Right
PLAYLIST	Left Tv	SHIFT +	Shift + Left
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Guide/Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
RETURN	Return Tv	SHIFT + RETURN BACK	Shift + Back
Q SETUP	Setup Tv	SHIFT + HOME SMART	Shift + Smart

Originalfernbedienung		Ersatzfernbedienung	
SEARCH MOVIE/TV A	Movie/TV/Search	SETTINGS OPT	Options
REPEAT MUSIC B	Music/Repeat	SOUND DUAL	Dual
RANDOM GAME C	Game/Random	AD SUBT	Subt
MODE THX D	Stereo/Play Mode	SEARCH TV/R	TV/R
1	1 Tv	SHIFT + 1	Shift + 1
2	2 Tv	SHIFT + 2	Shift + 2
3	3 Tv	SHIFT + 3	Shift + 3
4	4 Tv	SHIFT + 4	Shift + 4
5	5 Tv	SHIFT + 5	Shift + 5
6	6 Tv	SHIFT + 6	Shift + 6
7	7 Tv	SHIFT + 7	Shift + 7
8	8 Tv	SHIFT + 8	Shift + 8
9	9 Tv	SHIFT + 9	Shift + 9
11 0	0/11 Tv	SHIFT + 0	Shift + 0
+10 D.TUN DIMMER	+10/--/--10 Tv	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	SHIFT + FAV PRE-CH	Shift + Pre Ch
VOL	Vol + Tv	SHIFT + SOUND DUAL	Shift + Dual

Originalfernbedienung		Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
VOL	Vol - Tv	SHIFT + SETTINGS OPT		
AUX	AUX	REPEAT TEXT		
TV/CD	TV / CD	PICTURE FORMAT		
CBL/SAT	CBL/SAT	ECO 3D		
FM	FM	SHIFT + AD SUBT		
BD/DVD	DVD / BD	SHIFT + REPEAT TEXT		
GAME	Game	SHIFT + SEARCH TV/R		
STB/DVR	VCR / DVR	SHIFT + TIMER AV		
PC	PC	ZOOM ⏏		
USB	USB	DISC NAV LIST		
NET	NET	SHIFT + ZOOM ⏏		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power BD/DVD		Power
MENU PREV CH	Menu/Prev CH	TOP MENU MENU	Menu
TOP MENU GUIDE	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
Q SETUP	Setup BD/DVD	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Home/Audio	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
PLAYLIST	Right BD/DVD		Right
PLAYLIST	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
	Play BD/DVD	PLAY MODE	Play
	Pause/Play rev. BD/DVD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV A	Movie Tv/Search BD/DVD	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer BD/DVD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

BD/DVD

Originalfernbedienung	Ersatzfernbedienung
CBL/SAT	TEXT
Vol + Receiver	+ VOL
Vol - Receiver	VOL −
Power CBL/SAT	SHIFT + Power
CH Disc/Album+ CBL/SAT	+ CH
CH Disc/Album- CBL/SAT	CH −
Menu/Prev CH CBL/SAT	SHIFT + TOP MENU MENU
Top Menu/Guide CBL/SAT	SHIFT + SETTINGS OPT
Return CBL/SAT	SHIFT + RETURN BACK
Setup CBL/SAT	SHIFT + HOME SMART
Up CBL/SAT	SHIFT + ▲
Enter CBL/SAT	SHIFT + OK
Down CBL/SAT	SHIFT + ▼
Right CBL/SAT	SHIFT + ▶
Left CBL/SAT	SHIFT + ◀
Pause/Play rev. CBL/SAT	SHIFT + ❚❚
Stop CBL/SAT	SHIFT + ■

Originalfernbedienung	Ersatzfernbedienung
<< CBL/SAT	SHIFT + CH − Shift + Ch -
>> CBL/SAT	SHIFT + + CH Shift + Ch +
Play CBL/SAT	ECO 3D 3D
Movie Tv/Search CBL/SAT	SOUND DUAL Dual
Music/Repeat CBL/SAT	AD SUBT Subt
Game/Random	TIMER AV AV
Stereo/Play Mode CBL/SAT	PICTURE FORMAT Format
1 CBL/SAT	SHIFT + 1 Shift + 1
2 CBL/SAT	SHIFT + 2 Shift + 2
3 CBL/SAT	SHIFT + 3 Shift + 3
4 CBL/SAT	SHIFT + 4 Shift + 4
5 CBL/SAT	SHIFT + 5 Shift + 5
6 CBL/SAT	SHIFT + 6 Shift + 6
7 CBL/SAT	SHIFT + 7 Shift + 7
8 CBL/SAT	SHIFT + 8 Shift + 8
9 CBL/SAT	SHIFT + 9 Shift + 9
0/11 CBL/SAT	SHIFT + 0 Shift + 0

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
BD/DVD DVD/ BD	SEARCH TV/R TV/ R		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power CD		Power
CH DISC +	CH/Disc+ CD	CH +	Ch +
ALBUM −	CH/Disc- CD	CH −	Ch -
RETURN	Return CD	RETURN BACK	Back
SETUP	Setup CD	HOME SMART	Smart
AUDIO HOME	Home/Audio CD	APP MEDIA	Media
	Up CD		Up
	Down CD		Down
PLAYLIST	Right CD		Right
PLAYLIST	Left CD		Left
ENTER	Enter CD	OK	Ok
	I<< CD		I<<
	>>I CD		>>I
	<< CD		<<
	>> CD		>>
	Play CD	PLAY MODE	Play
	Pause CD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop CD		Stop
SEARCH MOVIE/TV A	Movie Tv/Search	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode	D	Blue
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
11 0	0/11 CD	0	0
10 +10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer CD	-/-- GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Originalfernbedienung		Ersatzfernbedienung	
VOL	Vol + Recei ver	+ VOL	Vol +
VOL	Vol - Recei ver	VOL –	Vol -
TV/CD	TV/ CD	SEARCH TV/R	TV/ R

Originalfernbedienung	Ersatzfernbedienung

Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver Zone 2		Power
VOL	Vol + Zone 2	VOL +	Vol +
VOL	Vol - Zone 2	VOL −	Vol -
CH DISC	CH Disc/Album+ Zone 2	CH +	Ch +
ALBUM	CH Disc/Album- Zone 2	CH −	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
PLAYLIST	Right Zone 2		Right
PLAYLIST	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
SETUP	Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Audio Zone 2	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
	Play Zone 2	PLAY MODE	Play
	>> Zone 2		>>

Originalfernbedienung		Ersatzfernbedienung	
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV A	Movie Tv/Search Zone 2	A	Red
REPEAT MUSIC B	Music/Repeat	B	Green
RANDOM GAME C	Game/Random	C	Yellow
MODE THX D	Stereo/Play Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9
11 0	0/11 Zone 2	0	0

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
+10/ - - / - - 10/ D. Tu Dimmer Zone 2	Guide		
CLR/ Sleep/ 12	Pre Ch		