| Originalfernbedienung | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|
| Power | Power | | |
| CD | 3 | | |
| Tape 1/2 | 5 | | |
| Tuner | 6 | | |
| AUX | 7 | | |
| DBB | Guide / EPG / -/-- | | |
| DSC | Fav / Marker / PC | | |
| Volume+ | Vol + | | |
| Volume- | Vol - | | |
| Mute | Mute / Dimmer | | |
| >I | >>I / Preset+ | | |
| I< | I<< / Preset- | | |
| >> | >> / Tune+ | | |
| << | << / Tune- | | |
| Program | TV/Radio / | | |
| | | | |
| | | | |

| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| | Power | | Power |
| CD | CD | CD - STB 3 | 3 |
| TAPE 1/2 | Tape 1/2 | TAPE 5 | 5 |
| TUNER | Tuner | TUNER 6 | 6 |
| AUX | AUX | AUX - HDD 7 | 7 |
| 1 | CD Direct 1 | TV 1 | 1 |
| CD DIRECT 2 | CD Direct 2 | DVD 2 | 2 |
| 3 | CD Direct 3 | VIDEO 4 | 4 |
| DBB | DBB | -/-- GUIDE EPG | Guide / EPG / -/-- |
| DSC | DSC | PC FAV MARKER | Fav / Marker / PC |
| + | Volume+ | + VOL | Vol + |
| − | Volume- | VOL − | Vol - |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| PAUSE | Pause | STEP - FREEZE | Pause / Step / Freeze |
| ▶ | Play | SLOW ▶ | Play / Slow |
| ▶\| | >\| | PRESET+ ▶▶\| | >>\| / Preset+ |
| \|◀ | \|< | PRESET- \|◀◀ | \|<< / Preset- |

| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| ■ | Stop | HOLD ■ | Stop / Hold |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- |
| REPEAT | Repeat | APP REPEAT | Green / APP / Repeat |
| SHUFFLE | Shuffle | Prime Video RANDOM | Blue / Prime Video / Random |
| PROGRAM | Program | PROGRAM TV/RADIO | TV/Radio / |

| Originalfernbedienung | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|
| Power | Power | | |
| CD | 3 | | |
| Tape 1/2 | 5 | | |
| Tuner | 6 | | |
| AUX | 7 | | |
| DBB | Guide / EPG / -/-- | | |
| DSC | Fav / Marker / PC | | |
| Volume+ | Vol + | | |
| Volume- | Vol - | | |
| Mute | Mute / Dimmer | | |
| Pause | Pause / Step / Freeze | | |
| Play | Play / Slow | | |
| >I | >>I / Preset+ | | |
| I< | I<< / Preset- | | |
| Stop | Stop / Hold | | |
| >> | >> / Tune+ | | |
| << | << / Tune- | | |

| Originalfernbedienung | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|
| Power | Power | | |
| CD | 3 | | |
| Tape 1/2 | 5 | | |
| Tuner | 6 | | |
| AUX | 7 | | |
| DBB | Guide / EPG / -/-- | | |
| DSC | Fav / Marker / PC | | |
| Volume+ | Vol + | | |
| Volume- | Vol - | | |
| Mute | Mute / Dimmer | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |