Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	Recall	RETURN BACK	Back / Return
+ VOL	Vol +	+ VOL	Vol +
DISP	Disp	MEDIA DISPLAY	Display / Media
+ CH	CH+	+ CH PAGE	CH+ / Page+

Originalfernbedienung		Ersatzfernbedienung	
VOL –	Vol -	VOL –	Vol -
INPUT	Input	RDS AV INPUT	AV / Input / RDS
CH –	CH-	CH PAGE –	CH- / Page-
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
▲	Up	▲	Up
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
◀	Left	◀	Left
ENTER	Enter	OK	OK
▶	Right	▶	Right
▼	Down	▼	Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MENU	Menu	HOME MENU	Menu / Home
PMODE	P. Mode	FORMAT PICTURE	Picture / Format
SMODE	S. Mode	TITLE SOUND	Sound / Title
AUTO	Auto	LIST SMART	Smart / List
ANGLE	Angle	ANGLE INFO	Info / Angle
⏮	I<<	PRESET- ⏮	I<< / Preset-

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
	>>I	PRESET+	>>I / Preset +		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
	Open/Close	SURROUND	Eject / Surround		
	Play/Pause	SLOW	Play / Slow		
	Stop	HOLD	Stop / Hold		
	II>/Step	STEP-FREEZE	Pause / Step / Freeze		
SETUP	Red/Setup	NETFLIX SEARCH	Red / Netflix / Search		
MENU	Green/Menu	APP REPEAT	Green / APP / Repeat		
TITLE	Yellow/Title	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
LANG	Blue/Lang	Prime Video RANDOM	Blue / Prime Video / Random		