Originalfernbedienung		Ersatzfernbedienung	
	Power		Power
	Eco		Fav / Marker / PC
	Net		Display / Media
	Net Radio 1		1
	Net Radio 2		2
	Net Radio 3		3
	HDMI 1		4
	HDMI 2		5
	Bluetooth		Shift + 9
	HDMI 3		7
	HDMI 4		8
	Optical		9
	TV		TV/ Radio /
	AUX1		Guide / EPG / -/--
	AUX2		0
	System Memory		Shift + 1
	System Memory		Shift + 2

Originalfernbedienung		Ersatzfernbedienung	
	System Memory		Shift + 3
	Sub+		CH+ / Page+
	Sub-		CH- / Page-
	Dialog Lift		Smart / List
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute / Dimmer
	Setup		Setup / OPT /
	Option		Shift + Setup / OPT / Tools
	Return		Back / Return
	Info		Info / Angle
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		OK
	Movie		Red / Netflix / Search

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
MUSIC	Music	APP / REPEAT	Green / APP / Repeat		
ENTER TAINMENT	Entertainment	YouTube / REPEAT A-B	Yellow / YouTube / Repeat		
OFF	Off	Prime Video / RANDOM	Blue / Prime Video / Random		
3D SURROUND	3D Surround	LANG I/II / AUDIO	Audio / Lang I/II		
SURROUND	Surround	SURROUND	Eject / Surround		
STEREO	Stereo	TITLE / SOUND	Sound / Title		
TARGET	Target	FORMAT / PICTURE	Picture / Format		
CLEAR VOICE	Clear Voice	CLEAR / EXIT / CANCEL	Exit / Cancel / Clear		
ENHANCER	Enhancer	SIZE / ZOOM	Zoom / Size		
CONNECT	Connect	GOTO / TEXT	Text / Goto		
WPS / CH LEVEL	WPS/CH Level	EQ / SUBTITLE	Subtitle / EQ		