Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	AD		Sound / Title
	0		0
	Source		AV / Input / RDS
	Vol +		Vol +
	ATV/DTV/Content Menu		Smart / List
	P+		CH+ / Page+
	Vol -		Vol -

Original		Replacement	
	Mute		Mute / Dimmer
	P-		CH- / Page-
	Guide/Top		D.Menu / Top
	Guide/Top		Guide / EPG / -/--
	Exit/Return		Back / Return
	Exit/Return		Exit / Cancel / Clear
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Menu/DVD		Menu / Home
	Down		Down
	Tv/FAV/Radio/Set		TV/Radio /
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

Original		Replacement		Original	Replacement
	[<>]	FORMAT PICTURE	Picture / Format		
	←[/]→	MEDIA DISPLAY	Display / Media		
	[i +] / [≡i]	ANGLE INFO	Info / Angle		
AUDIO TEXT	Text	GOTO TEXT	Text / Goto		
AUDIO TEXT	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
SUBTITLE	Eject	SURROUND	Eject / Surround		
CD I/II	O) I / II	SHIFT + LANG I/II AUDIO	Shift + Audio / Lang I/II		
CD I/II	Stop	HOLD	Stop / Hold		
	Play/ [≡o]	SLOW	Play / Slow		
	II / II >/ [▼]	STEP-FREEZE	Pause / Step / Freeze		
	I <</ [≡?]	PRESET-	I << / Preset-		
	<</ [≡+]	TUNE-	<< / Tune-		
	>>/ [≡♦]	TUNE+	>> / Tune+		
CD/VCD	>>I / [O] / [≡X]	PRESET+	>>I / Preset+		

Original		Replacement	
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Source		AV / Input / RDS
	Vol +		Vol +
	Vol -		Vol -
	Mute		Mute / Dimmer
	Guide/Top Menu		Guide / EPG / -/--
	Guide/Top Menu		D.Menu / Top Menu

Original		Replacement	
	Exit/Return		Exit / Cancel / Clear
	Exit/Return		Back / Return
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Menu/DVD		Menu / Home
	Down		Down
	Tv/FAV/Radio/Set		TV/Radio /
	Tv/FAV/Radio/Set		Setup / OPT /
	[<>]		Picture / Format
	←[/]→		Display / Media
	[i+]/[≡i]		Info / Angle
	Text		Text / Goto
	Audio		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	Eject		Eject / Surround

Original	Replacement
CD I/II	SHIFT + LANG I/II AUDIO Shift + Audio / Lang I/II
CD I/II Stop	HOLD Stop / Hold
Play/[≡o]	SLOW Play / Slow
II/II>/[▼]	STEP-FREEZE Pause / Step / Freeze
I<<</[≡?]	PRESET- I<< / Preset-
<<</[≡+]	TUNE- << / Tune-
>>/[≡♦]	TUNE+ >> / Tune+
>>I/[O]/[≡X]	PRESET+ >>I / Preset+

Original	Replacement

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
AD	Sound / Title
0	0
Source	AV / Input / RDS
Vol +	Vol +
ATV/DTV/Content Menu	Setup / OPT /
P+	CH+ / Page+
Vol -	Vol -

Original	Replacement
Mute	Mute / Dimmer
P-	CH- / Page-
Guide/Top	Guide / EPG / -/--
Guide/Top	D.Menu / Top
Exit/Return	Exit / Cancel / Clear
Exit/Return	Back / Return
Up	Up
Left	Left
OK	OK
Right	Right
Menu/DVD	Menu / Home
Down	Down
Tv/FAV/Radio/Set	TV/Radio /
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random

Original		Replacement		Original		Replacement	
	[<>]	FORMAT PICTURE	Picture / Format				
	←[/]→	MEDIA DISPLAY	Display / Media				
	[i +] / [≡i]	ANGLE INFO	Info / Angle				
AUDIO TEXT	Text	GOTO TEXT	Text / Goto				
AUDIO TEXT	Audio	LANG I/II AUDIO	Audio / Lang I/II				
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ				
SUBTITLE	Eject	SURROUND	Eject / Surround				
CD I/II	O) I / II	SHIFT +	LANG I/II AUDIO	Shift + Audio / Lang I/II			
CD I/II	Stop	HOLD	Stop / Hold				
	Play/ [≡o]	SLOW	Play / Slow				
	II / II >/ [▼]	STEP-FREEZE	Pause / Step / Freeze				
	I <</ [≡?]	PRESET-	I << / Preset-				
	<</ [≡+]	TUNE-	<< / Tune-				
	>>/ [≡♦]	TUNE+	>> / Tune+				
CD/VCD	>>I / [O] / [≡X]	PRESET+	>>I / Preset+				