Original	Replacement
Tv	TV/ Radio /
Power	Power
World	Smart / List
[≡] / Text	Text / Goto
Sleep	Sleep / Timer
Music/ Movie/ Phot	Sound / Title
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Source/ Games	AV / Input / RDS
0	0

Original	Replacement
Recall	Shift + Back / Return
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Vol +	Vol +
Mute	Mute / Dimmer
PR+	CH+ / Page+
Vol -	Vol -
i	Info / Angle
PR-	CH- / Page-
Menu	Menu / Home
Up	Up
Q. Menu	D. Menu / Top
Left	Left
OK	OK
Right	Right

Original		Replacement		Original	Replacement
BACK	Back	RETURN BACK	Back / Return		
	Down		Down		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	[≡] . .	OPT-TOOLS SETUP	Setup / OPT /		
LANG	Lang	LANG I/II AUDIO	Audio / Lang I/II		
	Q/ *	SIZE ZOOM	Zoom / Size		
	Q. . / *	FORMAT PICTURE	Picture / Format		
	Play	SLOW	Play / Slow		
	Stop	HOLD	Stop / Hold		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Rec	REC MODE	Rec / Rec Mode		
	Guide	-/-- GUIDE EPG	Guide / EPG / -/--		
	[- O-]	MEDIA DISPLAY	Display / Media		