Original	Replacement	Original	Replacement
Power	Power	Exit	Exit
Mute	Mute	Up	Up
1	1	Down	Down
2	2	Right	Right
3	3	Left	Left
4	4	OK	Ok
5	5	CH+	Ch +
6	6	CH-	Ch -
7	7	Vol +	Vol +
8	8	Vol -	Vol -
9	9	TXT	Text
0	0	EPG	Guide
Subtl	Subt	Info	Info
Tv/SAT	TV/R	Audio	Dual
16:9	Format	M-P	Media
Timer	AV	↑	>>
Menu	Menu	↓	<<

Original		Replacement		Original	Replacement
FAV	FAV	FAV PRE-CH	Pre Ch		
RECALL	Recall	RETURN BACK	Back		
SAT	Red/ SAT	A	Red		
ZOOM	Green/ Zoom	B	Green		
PAUSE	Yellow/ Pause	C	Yellow		
TV/RADIO	Blue/ Tv/ Radio	D	Blue		