Original	Replacement	Original	Replacement
Power	Power	Left	Left
Rec	Rec / Rec Mode	Up	Up
Red	Red / Netflix / Search	Right	Right
I <<	I << / Preset-	OK	OK
Green/[ ]	Green / APP / Repeat	Down	Down
Stop	Stop / Hold	Vol +	Vol +
Yellow	Yellow / YouTube / Repeat	Mute	Mute / Dimmer
Play/[:≡]	Play / Slow	P+	CH+ / Page+
Blue/[■]	Blue / Prime Video / Random	Vol -	Vol -
>>I	>>I / Preset+	Smart ♪	Sound / Title
AV/[?]	AV / Input / RDS	P-	CH- / Page-
I-II/[≡I ≡]	Audio / Lang I/II	Smart [ ]	Smart / List
[<>]/[+]	Picture / Format	1	1
[-S-]	Zoom / Size	2	2
Menu	Menu / Home	3	3
[≡]	Text / Goto	4	4
Pause	Pause / Step / Freeze	5	5

Original		Replacement		Original	Replacement
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
[i+]	Info / Angle	ANGLE INFO	Info / Angle		
0	0	HDMI - SAT 0	0		
P<P	P<P	PC FAV MARKER	Fav / Marker / PC		

Original	Replacement	Original	Replacement
O	Eject / Surround	[≡]	Text / Goto
-O-	Subtitle / EQ	Left	Left
Power	Power	Up	Up
Rec	Rec / Rec Mode	Right	Right
I<<	I<< / Preset-	OK	OK
Red	Red / Netflix / Search	Down	Down
Green/[[ ]]	Green / APP / Repeat	Vol +	Vol +
Stop	Stop / Hold	Mute	Mute / Dimmer
Play	Play / Slow	P+	CH+ / Page+
Yellow / List	Yellow / YouTube / Repeat	Vol -	Vol -
>>I	>>I / Preset+	Smart ♪	Sound / Title
AV/[?]	AV / Input / RDS	P-	CH- / Page-
I-II/[≡≡]	Audio / Lang I/II	Smart [ ]	Smart / List
[<>]/[+]	Zoom / Size	1	1
PIP [■]	Picture / Format	2	2
Menu	Menu / Home	3	3
Pause	Pause / Step / Freeze	4	4

Original		Replacement		Original	Replacement
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
[i+]	[i+]	ANGLE INFO	Info / Angle		
0	0	HDMI - SAT 0	0		
P<P	P<P	PC FAV MARKER	Fav / Marker / PC		

Original		Replacement	
	Power		Power
	-O-	EQ SUBTITLE	Subtitle / EQ
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
AV	AV/[?]	RDS AV INPUT	AV / Input / RDS
I-II	I-II/[≡] [≡]	LANG I/II AUDIO	Audio / Lang I/II
	[<>]/[+]	SIZE ZOOM	Zoom / Size
	Pause	STEP-FREEZE II	Pause / Step / Freeze
	[≡]	GOTO TEXT	Text / Goto
	Left		Left
	Up		Up
	Right		Right
OK	OK	OK	OK
	Down		Down
VOL +	Vol +	VOL +	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P +	P+	CH PAGE +	CH+ / Page+

Original		Replacement	
VOL –	Vol -	VOL –	Vol -
♪	Smart ♪	TITLE SOUND	Sound / Title
P –	P-	CH PAGE –	CH- / Page-
	Smart [ ]	LIST SMART	Smart / List
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
P<P	P<P	PC FAV MARKER	Fav / Marker / PC