Mandis shop

Philips 996580007897

Original		Replacement	
	Power		Power
HDMI IN	HDMI In	A	Red
HDMI ARC	HDMI ARC	B	Green
OPTICAL	Optical	C	Yellow
AUDIO IN	Audio In	D	Blue
USB	USB	PICTURE FORMAT	Format
	Bluetooth	APP MEDIA	Media
SOURCE	Source	TIMER AV	AV
	I<		I<<
	Play	PLAY MODE	Play
	Pause		Pause
	>I		>>I
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
TREBLE	Treble+		Ch +
TREBLE	Treble-	CH −	Ch -

Original		Replacement	
BASS	Bass+		Up
BASS	Bass-		Down
MUSIC	Music	SOUND DUAL	Dual
SMART	Smart	HOME SMART	Smart
VOICE	Voice	AD SUBT	Subt
SURR	Surr.	SEARCH TV/R	TV/R
	Audio Sync+		Right
	Audio Sync-		Left
	Auto Vol On	3	3
	Auto Vol Off	1	1
	Night On	6	6
	Night Off	4	4
DIM	DIM	-/-- GUIDE	Guide