Mandis shop

RC4875

Original		Replacement	
	Power		Power
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
	TV	PROGRAM TV/ RADIO	TV/ Radio /
0	0	HDMI - SAT 0	0
	Recall	PC FAV MARKER	Fav / Marker / PC
+V	V+	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
+P	P+	+ CH PAGE	CH+ / Page+

Original		Replacement	
-V	V-	VOL -	Vol -
	World/Internet	LIST SMART	Smart / List
-P	P-	CH PAGE -	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
Q.MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
BACK	Back	RETURN BACK	Back / Return
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
i	i	ANGLE INFO	Info / Angle
	Music/Camera	MEDIA DISPLAY	Display / Media
	TV Guide	-/-- GUIDE EPG	Guide / EPG / -/--
*/O	*/O	SHIFT + TV 1	Shift + 1
*/Q	*/Q	SHIFT + DVD 2	Shift + 2

Original	Replacement	Original	Replacement
[≡] / Text	GOTO TEXT — Text / Goto		
Red	NETFLIX SEARCH — Red / Netflix / Search		
Green	APP REPEAT — Green / APP / Repeat		
Yellow	YouTube REPEAT A-B — Yellow / YouTube / Repeat		
Blue	Prime Video RANDOM — Blue / Prime Video / Random		
Lang	LANG I/II AUDIO — Audio / Lang I/II		
[≡] . .	TITLE SOUND — Sound / Title		
[- O-]	OPT-TOOLS SETUP — Setup / OPT /		
<<	TUNE- << — << / Tune-		
Pause	STEP-FREEZE II — Pause / Step / Freeze		
>>	TUNE+ >> — >> / Tune+		
Rec	REC MODE — Rec / Rec Mode		
Play	SLOW — Play / Slow		
Stop	HOLD — Stop / Hold		