Original		Replacement	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Replacement	
P	PR+	+ CH	Ch +
P	PR-	CH −	Ch -
CH LIST	CH List	DISC NAV LIST	List
CONTENT	Content	HOME SMART	Smart
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	i/Info	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
A	Red	A	Red
B	Green	B	Green

Original		Replacement		Original	Replacement
C	Yellow	C	Yellow		
D	Blue	D	Blue		
P.MODE	P. Mode	SHIFT + PICTURE FORMAT	Shift + Format		
3D	3D	ECO 3D	3D		
DUAL I-II	Dual I-II	SOUND DUAL	Dual		
E-MANUAL	E-Manual	E-MANUAL D.MENU	D. Menu		
P.SIZE	P. Size	PICTURE FORMAT	Format		
AD/SUBT.	AD/Subt.	AD SUBT	Subt		
<<<I<<	<<<I<<	<<	<<		
II	Pause	II	Pause		
>>I>>>	>>I>>>	>>	>>		
●	Rec	REC MODE ●	Rec		
▶	Play	PLAY MODE ▶	Play		
■	Stop	■	Stop		