Original		Replacement	
	Power		Power
TV/RAD	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
INPUT	Input	RDS AV INPUT	AV / Input / RDS
SETTINGS Q.MENU	Settings/Q.Men	TOP MENU D.MENU	D.Menu / Top
INFO	Info	ANGLE INFO	Info / Angle
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
1 .@	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD-STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX-HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
0	0	HDMI-SAT 0	0

Original		Replacement	
Q.VIEW	Q.View	MEDIA DISPLAY	Display / Media
	Vol +	+ VOL	Vol +
FAV	FAV	PC FAV MARKER	Fav / Marker / PC
P PAGE	PR+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
3D	3D	FORMAT PICTURE	Picture / Format
P PAGE	PR-	CH PAGE −	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
RECENT	Recent	PRESET-	I<< / Preset-
SMART	Smart	LIST SMART	Smart / List
LIVE MENU	Live Menu	HOME MENU	Menu / Home
TEXT	Text	GOTO TEXT	Text / Goto
	Up		Up
T.OPT	T.Opt	OPT-TOOLS SETUP	Setup / OPT /
	Left		Left
OK	OK	OK	OK
	Right		Right

Original		Replacement		Original		Replacement	
BACK	Back	RETURN BACK	Back / Return				
▼	Down	▼	Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
AD	AD	LANG I/II AUDIO	Audio / Lang I/II				
REC/*	Rec/*	REC MODE ●	Rec / Rec Mode				
■	Stop	HOLD ■	Stop / Hold				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
●	Red	NETFLIX SEARCH	Red / Netflix / Search				
●●	Green	APP REPEAT	Green / APP / Repeat				
●●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
●●	Blue	Prime Video RANDOM	Blue / Prime Video / Random				