Original		Replacement	
I/⏻	Power	⏻	Power
TV I/⏻	Tv Power	SHIFT + ⏻	Shift + Power
ONE-TOUCH PLAY	One Touch Play	HOME SMART	Smart
THEATRE	Theatre	APP MEDIA	Media
DVD/CD	1	1	1
FM	2	2	2
USB	3	3	3
TV	4	4	4
AUDIO IN	5	5	5
FUNCTION	6	6	6
TIME/ TEXT	7	7	7
SOUND MODE	8	8	8
SYSTEM MENU	9	9	9
SUBTITLE D.TUNING	0	0	0
DVD/CD	DVD/CD	D	Blue
FM	FM	B	Green
USB	USB	TIMER AV	AV

Original		Replacement	
TV	TV	C	Yellow
AUDIO IN	Audio In	A	Red
FUNCTION	Function	ECO 3D	3D
TIME/ TEXT	Time / Text	REPEAT TEXT	Text
SOUND MODE	Sound Mode	PICTURE FORMAT	Format
SYSTEM MENU	System Menu	TOP MENU MENU	Menu
CLEAR AUDIO	Audio	SOUND DUAL	Dual
CLEAR AUDIO	Clear	CLEAR EXIT	Exit
SUBTITLE D.TUNING	Subtitle / D. Tuning	AD SUBT	Subt
TV INPUT ANGLE MEM SEL	Angle / Mem Sel	SETTINGS OPT	Options
TV INPUT ANGLE MEM SEL	TV Input	SEARCH TV/R	TV/R
DVD TOP MENU	DVD Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
DVD MENU	DVD Menu	E-MANUAL D.MENU	D. Menu
VOLUME +	Volume +	+ VOL	Vol +
−	Volume -	VOL −	Vol -
MUTING	Muting	MUTE	Mute
DISPLAY	Display	DISPLAY INFO	Info

Original		Replacement	
RETURN	Return	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK	OK	Ok
PRESET−	I<< / Preset -		I<<
PRESET+	>>I / Preset +		>>I
	Pause		Pause
	Play	PLAY MODE	Play
	Stop		Stop
TUNING−	<< / Tuning - /		<<
TUNING+	>> / Tuning + /		>>

Original	Replacement