Mandis shop

BN59- 01069A

Original		Replacement	
POWER	Power		Power
SOURCE	Sour ce	TIMER AV	AV
HDMI	HDM	ECO 3D	3D
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/ M X	REPEAT TEXT	Text
PRE-CH	PRE- CH	FAV PRE-CH	Pr e Ch
	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -

Original		Replacement	
P	PR+	+ CH	Ch +
P	PR-	CH –	Ch -
MUTE	Mut e	MUTE	Mut e
CH LIST	CH. Li st	DISC NAV LIST	Li st
MEDIA.P	Medi a. P	APP MEDIA	Medi a
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Gui de	- / -- GUIDE	Gui de
TOOLS	Tool s	SETTINGS OPT	Opt i ons
INFO	I nf o	DISPLAY INFO	I nf o
RETURN	Ret ur n	RETURN BACK	Back
EXIT	Exi t	CLEAR EXIT	Exi t
	OK	OK	Ok
▲	Up	▲	Up
▼	Down	▼	Down
▶	Ri ght	▶	Ri ght
◀	Lef t	◀	Lef t
A	Red/ A	A	Red

Original		Replacement		Original	Replacement
B	Green/ B	B	Green		
C	Yellow/ C	C	Yellow		
D	Blue/ D	D	Blue		
@TV INTERNET	Internet / @Tv	HOME SMART	Smart		
S.MODE	S. Mode	SHIFT + SOUND DUAL	Shift + Dual		
ALARM	Alarm	PROG SLEEP	Sleep		
I-II DUAL	Dual / I - II	SOUND DUAL	Dual		
P.SIZE	P. Size	PICTURE FORMAT	Format		
SUBT.	Subt.	AD SUBT	Subt		
◀◀	<<	≪	<<		
▶▶	>>	≫	>>		
❚❚	Pause	❚❚	Pause		
●	Rec	REC MODE ●	Rec		
▶	Play	PLAY MODE ▶	Play		
■	Stop	■	Stop		