Original	Replacement	Original	Replacement
Standby	SHIFT + Shift + Power	Entertain	3
Power	Power	Movie	4
CD	SHIFT + CD-STB 3 Shift + 3	Standard	5
MD/CD-R	SHIFT + TAPE 5 Shift + 5	Select	6
Tuner	SHIFT + TUNER 6 Shift + 6	Exto Sur.	7
*	SHIFT + BLUETOOTH 9 Shift + 9	Direct ST	8
DVD	SHIFT + DVD 2 Shift + 2	Speakers	9
DTV/CBL	SHIFT + TV 1 Shift + 1	Enhancer	0
DVR	SHIFT + USB 8 Shift + 8	Night	Guide / EPG / -/--
V-AUX	SHIFT + AUX-HDD 7 Shift + 7	Straight	Fav / Marker / PC
Multi CH In	SHIFT + VIDEO 4 Shift + 4	Title/Level	Sound / Title
Sleep	TIMER SLEEP Sleep / Timer	Up	Up
Vol +	+ VOL Vol +	Set Menu	Menu / Home
Vol -	VOL − Vol -	Left/-	Left
Mute	DIMMER MUTE Mute / Dimmer	Enter	OK
Stereo	TV 1 1	Right/+	Right
Music	DVD 2 2	Return/Dab Memory	Back / Return

Original	Replacement	Original	Replacement
Down	Down		
Display	Display / Media		
System Power 2	Yellow / YouTube / Repeat		
Standby 2	Blue / Prime Video / Random		

Original	Replacement	Original	Replacement
Power AV	AV / Input / RDS	Sleep	Sleep / Timer
Standby	Shift + Power	<< DVD	<< / Tune-
Power	Power	Stop DVD	Stop / Hold
CD	Shift + 3	>> DVD	>> / Tune+
MD/CD-R	Shift + 5	Vol +	Vol +
Tuner	Shift + 6	Vol -	Vol -
*	Shift + 9	Mute	Mute / Dimmer
DVD	Shift + 2	1 DVD	1
DTV/CBL	Shift + 1	2 DVD	2
DVR	Shift + 8	3 DVD	3
V-AUX	Shift + 7	4 DVD	4
Disc Skip DVD	Text / Goto	5 DVD	5
Pause DVD	Pause / Step / Freeze	6 DVD	6
Multi CH In	Shift + 4	7 DVD	7
I << DVD	I << / Preset-	8 DVD	8
Play DVD	Play / Slow	9 DVD	9
>>I DVD	>>I / Preset+	0 DVD	0

Original		Replacement		Original	Replacement
NIGHT +10	+10 DVD	-/-- GUIDE EPG	Guide / EPG / -/--		
STRAIGHT ENT.	ENT DVD	PC FAV MARKER	Fav / Marker / PC		
LEVEL TITLE BAND	Title DVD	TITLE SOUND	Sound / Title		
^	Up DVD	▲	Up		
SET MENU MENU SRCH MODE	Menu/Set Menu/Search	HOME MENU	Menu / Home		
< A/B/C/D/E	Left/- DVD	◀	Left		
ENTER	Enter DVD	OK	OK		
> A/B/C/D/E	Right/+ DVD	▶	Right		
RETURN DAB MEMORY	Return/DAB Memory DVD	RETURN BACK	Back / Return		
∨ PRESET/CH	Down DVD	▼	Down		
DISPLAY	Display DVD	MEDIA DISPLAY	Display / Media		

Original	Replacement	Original	Replacement
Standby	Shift + Power	<< CD	<< / Tune-
Power	Power	Stop CD	Stop / Hold
CD	Shift + 3	>> CD	>> / Tune+
MD/CD-R	Shift + 5	Vol +	Vol +
Tuner	Shift + 6	Vol -	Vol -
*	Shift + 9	Mute	Mute / Dimmer
DVD	Shift + 2	1 CD	1
DTV/CBL	Shift + 1	2 CD	2
DVR	Shift + 8	3 CD	3
V-AUX	Shift + 7	4 CD	4
Disc Skip CD	Text / Goto	5 CD	5
Pause CD	Pause / Step / Freeze	6 CD	6
Multi CH In	Shift + 4	7 CD	7
I << CD	I << / Preset-	8 CD	8
Play CD	Play / Slow	9 CD	9
>>I CD	>>I / Preset+	0 CD	0
Sleep	Sleep / Timer	+10 CD	Guide / EPG / -/--

Original	Replacement	Original	Replacement
ENT CD	Fav / Marker / PC		
Title/Level/Band	Sound / Title		
Up	Up		
Set Menu	Menu / Home		
Left/-	Left		
Enter	OK		
Right/+	Right		
Return/Dab	Back / Return		
Down	Down		
Display CD	Display / Media		

Original	Replacement	Original	Replacement
Standby	SHIFT + Shift + Power	Vol -	Vol -
Power	Power	Mute	Mute / Dimmer
CD	SHIFT + CD-STB 3 Shift + 3	1 Tuner	TV 1 1
MD/CD-R	SHIFT + TAPE 5 Shift + 5	2 Tuner	DVD 2 2
Tuner	SHIFT + TUNER 6 Shift + 6	3 Tuner	CD-STB 3 3
*	SHIFT + BLUETOOTH 9 Shift + 9	4 Tuner	VIDEO 4 4
DVD	SHIFT + DVD 2 Shift + 2	5 Tuner	TAPE 5 5
DTV/CBL	SHIFT + TV 1 Shift + 1	6 Tuner	TUNER 6 6
DVR	SHIFT + USB 8 Shift + 8	7 Tuner	AUX-HDD 7 7
V-AUX	SHIFT + AUX-HDD 7 Shift + 7	8 Tuner	USB 8 8
Multi CH In	SHIFT + VIDEO 4 Shift + 4	9 Tuner	BLUETOOTH 9 9
Freq/Text Tuner	PRESET- I << / Preset-	0 Tuner	HDMI-SAT 0 0
EON Tuner	PRESET+ >>I / Preset+	ENT Tuner	PC FAV MARKER Fav / Marker / PC
Sleep	TIMER SLEEP Sleep / Timer	Band Tuner	SLOW Play / Slow
PTY Seek Mode	TUNE- << / Tune-	Up Tuner	Up
PTY Seek Start Tuner	TUNE+ >> / Tune+	Search Mode	NETFLIX SEARCH Red / Netflix / Search
Vol +	VOL Vol +	Left/- Tuner	Left

Original		Replacement		Original	Replacement
ENTER	Enter Tuner	OK	OK		
A/B/C/D/E	Right / + Tuner		Right		
RETURN DAB MEMORY	DAB Memory	RETURN BACK	Back / Return		
PRESET/CH	Down Tuner		Down		
DISPLAY	Display Tuner	MEDIA DISPLAY	Display / Media		