Original		Replacement	
	Power		Power
	Red/ Sound↑	A	Red
	Green/ Picture/ ↓	B	Green
	Yellow/ Feature	C	Yellow
	Blue/ Install	D	Blue
	[≡]	REPEAT TEXT	Text
	[≡0]	SETTINGS OPT	Options
	[≡+]	AD SUBT	Subt
	[≡x] / [· ·]	PICTURE FORMAT	Format
	[/ ≡] / [*]	RETURN BACK	Back
	[+] ([≡♦] / Wide	ECO 3D	3D
	[≡?] / PC	HOME SMART	Smart
	[≡i] / Guide	-/-- GUIDE	Guide
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4

Original		Replacement	
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
P<P	P<P	FAV PRE-CH	Pre Ch
-/-- EXIT	-/--	SHIFT + -/-- GUIDE	Shift + Guide
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
	P+	+ CH	Ch +
	P-	CH −	Ch -
I-II	I-II	SOUND DUAL	Dual
INFO	[i] / Info	DISPLAY INFO	Info
TV/DTV	TV/DTV	SEARCH TV/R	TV/R
AV	AV	TIMER AV	AV

Original		Replacement	
	PP		Medi a
	Up		Up
	Down		Down
	Ri ght		Ri ght
	Lef t		Lef t
	OK/ Sel ect		Ok
	M		Menu

Original	Replacement