Original		Replacement	
ON/STAND-BY	On/Standby		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
MEMORY	Memory	FAV PRE-CH	Pre Ch
CLEAR	Clear	CLEAR EXIT	Exit
CLOCK/TIMER	Clock/Timer	TIMER AV	AV
SLEEP	Sleep	PROG SLEEP	Sleep
REPEAT	Repeat	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
10+	10+	-/-- GUIDE	Guide
BASS/TREBLE	Bass/Treble	SETTINGS OPT	Options
X-BASS	X-Bass	SOUND DUAL	Dual
RANDOM	Random	AD SUBT	Subt
TUNING	<<I <<I Tuning		I <<
TUNING	Tuning		>>I
FOLDER	Folder	RETURN BACK	Back
DEMO/DIMMER	Demo/Dimmer	ECO 3D	3D
PRESET	Preset Up		Up
PRESET	Preset Down		Down
ENTER	Enter	OK	Ok
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
CD	CD	C	Yellow
USB	USB	D	Blue
TUNER (BAND)	Band/Tuner	B	Green

Original		Replacement	
AUDIO/LINE INPUT	Input/Audio/Line	A	Red
iPod	iPod	HOME SMART	Smart
DISPLAY (TV OUT)	(Tv Out)/Display	SEARCH TV/R	TV/R
MENU	Menu	TOP MENU MENU	Menu
►/II	Play/Pause Ipod	II	Pause
DISPLAY	Display CD/USB	DISPLAY INFO	Info
■	Stop CD/USB	■	Stop
►/II	Play/Pause	PLAY MODE ►	Play
NETWORK	Network	APP MEDIA	Media

Original	Replacement