Original	Replacement
Power	Power
ShowView	Smart / List
Rec Check	Shift + Rec / Rec Mode
Ext Link	Text / Goto
Rec	Rec / Rec Mode
1	1
2	2
3	3
Tracking/V-Lock+	CH+ / Page+
4	4
5	5
6	6
Tracking/V-Lock-	CH- / Page-
7	7
8	8
9	9
Vol +	Vol +

Original	Replacement
AV/Input Selec	AV / Input / RDS
0	0
-/--	Guide / EPG / -/--
Vol -	Vol -
Index <<	<< / Preset-
Index >>I	>>I / Preset+
<<	<< / Tune-
>>	>> / Tune+
Stop	Stop / Hold
Pause/Step	Pause / Step / Freeze
Play	Play / Slow
Prog Play	D.Menu / Top
Up	Up
Menu	Menu / Home
Left	Left
Enter	OK
Right	Right

Original	Replacement	Original	Replacement
Display	Display / Media		
Down	Down		
Exit	Exit / Cancel / Clear		
Prog/Check	TV/Radio /		
Timer	Sleep / Timer		
Output	Subtitle / EQ		
AV Link	Eject / Surround		
Audio	Audio / Lang I/II		
Music w/Picture	Setup / OPT /		
Tv Aspect/Off	Picture / Format		
A/Cancel Reset	Red / Netflix / Search		
B/I-Timer	Green / APP / Repeat		
C/SP/LP/EP	Yellow / YouTube / Repeat		
D/VPS/PDC	Blue / Prime Video / Random		

Original		Replacement	
VCR/DVD	Power		Power
REC CHECK	Rec Check	SHIFT + REC MODE	Shift + Rec / Rec Mode
EXT LINK	Ext Link	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
TRACKING/V-LOCK CH	Tracking/V-Lock/	+ CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	Tracking/V-Lock/	CH PAGE −	CH- / Page-
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
VOLUME +	Vol +	+ VOL	Vol +
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0

Original		Replacement	
-/--	>10	GUIDE EPG	Guide / EPG / -/--
−	Vol -	VOL −	Vol -
INDEX/	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
SLOW/SEARCH	<< Slow/Search	TUNE-	<< / Tune-
SEARCH	Slow/Search >>	TUNE+	>> / Tune+
■	Stop	HOLD ■	Stop / Hold
II/I▸	Pause/Step	STEP-FREEZE II	Pause / Step / Freeze
▸	Play	SLOW ▸	Play / Slow
PROG PLAY / DIRECT NAVIGATOR	Top Menu/Direct Navigator	TOP MENU D.MENU	D.Menu / Top
▲	Up	▲	Up
MENU / PLAY LIST	Play List	LIST SMART	Smart / List
◂	Left	◂	Left
ENTER	Enter	OK	OK
▸	Right	▸	Right
DISPLAY	Display	MEDIA DISPLAY	Display / Media
▾	Down	▾	Down

Original	Replacement	Original	Replacement
EXIT / RETURN — Return	RETURN / BACK — Back / Return		
TIMER — Timer	TIMER / SLEEP — Sleep / Timer		
QUICK REPLAY — Quick Replay	HOME / MENU — Menu / Home		
VCR/DVD / OUTP — Output	SURROUND — Eject / Surround		
AV LINK/SUBTITLE — Subtitle	EQ / SUBTITLE — Subtitle / EQ		
AUDIO — Audio	LANG I/II / AUDIO — Audio / Lang I/II		
ANGLE/PAGE — Angle/Page	ANGLE / INFO — Info / Angle		
MUSIC w/PICTURE — Music w/Pictur	FORMAT / PICTURE — Picture / Format		
OFF TIMER / TV ASPECT — Play Mode	TITLE / SOUND — Sound / Title		
ZOOM — Zoom	SIZE / ZOOM — Zoom / Size		
REPEAT — Repeat	SHIFT + APP / REPEAT — Shift + Green / APP /		
POSITION MEMORY — Position	PC / FAV MARKER — Fav / Marker / PC		
CANCEL/RESET / A — A/Cancel Reset	NETFLIX / SEARCH — Red / Netflix / Search		
I-TIMER / B / CINEMA — B/Cinema	APP / REPEAT — Green / APP / Repeat		
SP/LP/EP / C / GROUP — C/Group	YouTube / REPEAT A-B — Yellow / YouTube / Repeat		
VPS/PDC / D / SETUP — D/Setup	Prime Video / RANDOM — Blue / Prime Video / Random		

Original		Replacement		Original		Replacement	
TV	Power		Power	OFF TIMER / TV ASPECT	Tv Aspect	FORMAT / PICTURE	Picture / Format
1	1	TV 1	1	CANCEL/RESET A	A	NETFLIX / SEARCH	Red / Netflix / Search
2	2	DVD 2	2	I-TIMER B	B	APP / REPEAT	Green / APP / Repeat
3	3	CD - STB 3	3	SP/LP/EP C	C	YouTube / REPEAT A-B	Yellow / YouTube / Repeat
TRACKING/V-LOCK CH	CH+	CH PAGE +	CH+ / Page+	VPS/PDC D	D	Prime Video / RANDOM	Blue / Prime Video / Random
4	4	VIDEO 4	4				
5	5	TAPE 5	5				
6	6	TUNER 6	6				
CH	CH-	CH PAGE −	CH- / Page-				
7	7	AUX - HDD 7	7				
8	8	USB 8	8				
9	9	BLUETOOTH 9	9				
VOLUME +	Vol +	VOL +	Vol +				
INPUT SELECT AV	AV/Input Selec	RDS AV INPUT	AV / Input / RDS				
0	0	HDMI - SAT 0	0				
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--				
−	Vol -	VOL −	Vol -				