| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| TV I/⏻ STANDBY | Power | ⏻ | Power | 8 | 8 | 8 | 8 |
| AV I/⏻ SYSTEM | Power AV | SHIFT + ⏻ | Shift + Power | 9 | 9 | 9 | 9 |
| AUTO CAL | Auto Cal | HOME SMART | Smart | 0/10 | 0/10 | 0 | 0 |
| TV/VIDEO SLEEP | Sleep | PROG SLEEP | Sleep | >10/* -/-- CLEAR | -/--/>10 | -/-- GUIDE | Guide |
| MD/TAPE | MD-TAPE | APP MEDIA | Media | DUAL MONO | Dual Mono | SOUND DUAL | Dual |
| AMP MENU | AMP MENU | TOP MENU MENU | Menu | FM MODE | FM Mode | SEARCH TV/R | TV/R |
| 2CH | 2CH | A | Red | DISPLAY | Display | DISPLAY INFO | Info |
| A.F.D. | A.F.D. | B | Green | | Up AMP Menu | ▲ | Up |
| MOVIE | Movie | C | Yellow | | Down AMP | ▼ | Down |
| MUSIC | Music | D | Blue | | Right AMP Menu | ▶ | Right |
| 1 | 1 | 1 | 1 | | Left AMP Menu | ◀ | Left |
| 2 | 2 | 2 | 2 | | OK MD/Tape | SHIFT + OK | Shift + Ok |
| 3 | 3 | 3 | 3 | | OK AMP Menu | OK | Ok |
| 4 | 4 | 4 | 4 | TV VOL MASTER VOL + | Vol + | + VOL | Vol + |
| 5 | 5 | 5 | 5 | – | Vol - | VOL – | Vol - |
| 6 | 6 | 6 | 6 | MUTING | Muting | MUTE | Mute |
| 7 | 7 | 7 | 7 | TV CH – PRESET – | I<<</Preset- | << | I<< |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| TV CH + PRESET + | >>I / Preset + | >>I | >>I | | |
| TUNING − | <<I Tuning- | << | << | | |
| | Play | PLAY MODE ▶ | Play | | |
| TUNING + | >>I Tuning+ | >> | >> | | |
| | Pause | ❚❚ | Pause | | |
| | Stop | ■ | Stop | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Power AV | SHIFT + | Shift + Power |
| | Auto Cal | HOME SMART | Smart |
| | Sleep | PROG SLEEP | Sleep |
| 2CH | 2CH | A | Red |
| A.F.D. | A. F. D. | B | Green |
| MOVIE | Movie | C | Yellow |
| MUSIC | Music | D | Blue |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |

| Original | | Replacement | |
|---|---|---|---|
| 0/10 | 0/10 | 0 | 0 |
| >10/* -/-- CLEAR | -/--/>10 | -/-- GUIDE | Guide |
| MEMORY ENTER | Enter/Memory | FAV PRE-CH | Pre Ch |
| MENU | Menu | TOP MENU MENU | Menu |
| DVD MENU | DVD Menu | E-MANUAL D.MENU | D. Menu |
| RETURN/EXIT | Return/Exit | CLEAR EXIT | Exit |
| TOOLS | Tools | SETTINGS OPT | Options |
| DISPLAY | Display | DISPLAY INFO | Info |
| D.TUNING D.SKIP | D. Tuning/D. Skip | PICTURE FORMAT | Format |
| FM MODE | FM Mode | SEARCH TV/R | TV/R |
| DUAL MONO | Dual Mono | SOUND DUAL | Dual |
| MUTING | Muting | MUTE | Mute |
| TV VOL MASTER VOL + | Vol + | + VOL | Vol + |
| – | Vol - | VOL – | Vol - |
| | OK | OK | Ok |
| | Up | | Up |
| | Down | | Down |

| Original | | Replacement | |
|---|---|---|---|
| | Right | | Right |
| | Left | | Left |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| | Stop | | Stop |
| TUNING – | <<Tuning- | | << |
| TUNING + | >>Tuning+ | | >> |
| TV CH + PRESET + | >>I / Preset + | | >>I |
| TV CH – PRESET – | I<< / Preset - | | I<< |
| REPLAY | ← / Replay | CH – | Ch - |
| ADVANCE | · → / Advance | + CH | Ch + |
| DVD | DVD | APP MEDIA | Media |
| D.TUNING D.SKIP | D. Tuning/ D. Skip Tuner | ECO 3D | 3D |
| TUNER | Tuner | SHIFT + APP MEDIA | Shift + Media |
| MEMORY ENTER | Enter / Memory | SHIFT + FAV PRE-CH | Shift + Pre Ch |
| 1 | 1 Tuner | SHIFT + 1 | Shift + 1 |
| 2 | 2 Tuner | SHIFT + 2 | Shift + 2 |

| Original | | Replacement | |
|---|---|---|---|
| 3 | 3 Tuner | SHIFT + 3 | Shift + 3 |
| 4 | 4 Tuner | SHIFT + 4 | Shift + 4 |
| 5 | 5 Tuner | SHIFT + 5 | Shift + 5 |
| 6 | 6 Tuner | SHIFT + 6 | Shift + 6 |
| 7 | 7 Tuner | SHIFT + 7 | Shift + 7 |
| 8 | 8 Tuner | SHIFT + 8 | Shift + 8 |
| 9 | 9 Tuner | SHIFT + 9 | Shift + 9 |
| 0/10 | 0/10 Tuner | SHIFT + 0 | Shift + 0 |
| DISPLAY | Display Tuner | SHIFT + DISPLAY INFO | Shift + Info |
| | OK Tuner | SHIFT + OK | Shift + Ok |
| | Up Tuner | SHIFT + | Shift + Up |
| | Down Tuner | SHIFT + | Shift + Down |
| | Right Tuner | SHIFT + | Shift + Right |
| | Left Tuner | SHIFT + | Shift + Left |
| TUNING – | <<Tuning- Tuner | SHIFT + | Shift + << |
| TUNING + | >>Tuning+ | SHIFT + | Shift + >> |
| TV CH – PRESET – | I<< / Preset - / Tv CH- Tuner | SHIFT + | Shift + I<< |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| TV CH + PRESET + >>I / Preset +/ Tv CH+ Tuner | SHIFT + >>I Shift + >>I | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Play | PLAY MODE | Play |
| | Stop | | Stop |
| AUTO CAL | Auto Cal | HOME SMART | Smart |
| TV/VIDEO SLEEP | Sleep | PROG SLEEP | Sleep |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0/10 | 0/10 | 0 | 0 |
| >10/* -/-- CLEAR | -/--/>10 | -/-- GUIDE | Guide |
| | OK | OK | Ok |

| Original | | Replacement | |
|---|---|---|---|
| MEMORY ENTER | Enter/Memory | FAV PRE-CH | Pre Ch |
| MENU | Menu | TOP MENU MENU | Menu |
| DISPLAY | Display | DISPLAY INFO | Info |
| MUTING | Muting | MUTE | Mute |
| TV VOL MASTER VOL + | Vol + | + VOL | Vol + |
| − | Vol - | VOL − | Vol - |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| DUAL MONO | Dual Mono | SOUND DUAL | Dual |
| FM MODE | FM Mode | PICTURE FORMAT | Format |
| 2CH | 2CH | A | Red |
| A.F.D. | A.F.D. | B | Green |
| MOVIE | Movie | C | Yellow |
| MUSIC | Music | D | Blue |
| | Pause | | Pause |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| TUNING + | >>/ Tuning+ | >> | | | |
| TUNING – | <</ Tuning- | << | | | |
| TV CH + PRESET + | >>I / Preset + | >>I | | | |
| TV CH – PRESET – | I <</ Preset - | I << | | | |
| REPLAY | ← / Replay | CH – | Ch - | | |
| ADVANCE | · →/ Advance | + CH | Ch + | | |
| VIDEO 3 | Video 3 | SHIFT + APP MEDIA | Shift + Media | | |
| VIDEO 1 | Video 1 | APP MEDIA | Media | | |
| AV I/⏻ SYSTEM | Power AV | TIMER AV | AV | | |
| TV I/⏻ STANDBY | Tv Power | SHIFT + ⏻ | Shift + Power | | |
| TV/VIDEO SLEEP | Tv/ Video | SEARCH TV/R | TV/ R | | |
| TV VOL MASTER VOL + | Tv Vol + | SHIFT + + VOL | Shift + Vol + | | |
| – | Tv Vol - | SHIFT + VOL – | Shift + Vol - | | |
| TV CH – PRESET – | Tv CH- | SHIFT + CH – | Shift + Ch - | | |
| TV CH + PRESET + | Tv CH+ | SHIFT + + CH | Shift + Ch + | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| STANDBY | Power | | Power |
| AV I/⏻ SYSTEM | Power AV | SHIFT + | Shift + Power |
| AUTO CAL | Auto Cal | HOME SMART | Smart |
| TV/VIDEO SLEEP | Sleep | PROG SLEEP | Sleep |
| A.F.D. | A. F. D. | B | Green |
| MOVIE | Movie | C | Yellow |
| MUSIC | Music | D | Blue |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0/10 | 0/10 | 0 | 0 |

| Original | | Replacement | |
|---|---|---|---|
| >10/* -/-- CLEAR | -/--/>10 | -/-- GUIDE | Guide |
| MEMORY ENTER | Enter/Memory | FAV PRE-CH | Pre Ch |
| FM MODE | FM Mode | SEARCH TV/R | TV/R |
| DUAL MONO | Dual Mono | SOUND DUAL | Dual |
| DISPLAY | Display | DISPLAY INFO | Info |
| MUTING | Muting | MUTE | Mute |
| TV VOL MASTER VOL + | Vol + | + VOL | Vol + |
| – | Vol - | VOL – | Vol - |
| MENU | Menu | TOP MENU MENU | Menu |
| | OK | OK | Ok |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| | Stop | | Stop |

| Original | Replacement |
|---|---|
| TUNING – <<< Tuning- | << |
| TUNING + >>> Tuning+ | >> |
| TV CH + PRESET + >>I / Preset + | >>I |
| TV CH – PRESET – I<<< / Preset - | I << |
| REPLAY ← / Replay | CH – Ch - |
| ADVANCE → / Advance | + CH Ch + |
| VIDEO 2 Video 2 | APP MEDIA Media |
| SA-CD/CD SA-CD/CD | SHIFT + APP MEDIA Shift + Media |
| AV SYSTEM Power AV | TIMER AV AV |
| 2CH 2CH | A Red |
| D.TUNING D.SKIP D.Tuning/D.Skip SA-CD/CD | PICTURE FORMAT Format |
| MEMORY ENTER Enter/Memory SA-CD/CD | SHIFT + FAV PRE-CH Shift + Pre Ch |
| 1 1 SA-CD/CD | SHIFT + 1 Shift + 1 |
| 2 2 SA-CD/CD | SHIFT + 2 Shift + 2 |
| 3 3 SA-CD/CD | SHIFT + 3 Shift + 3 |
| 4 4 SA-CD/CD | SHIFT + 4 Shift + 4 |
| 5 5 SA-CD/CD | SHIFT + 5 Shift + 5 |

| Original | Replacement |
|---|---|
| 6 6 SA-CD/CD | SHIFT + 6 Shift + 6 |
| 7 7 SA-CD/CD | SHIFT + 7 Shift + 7 |
| 8 8 SA-CD/CD | SHIFT + 8 Shift + 8 |
| 9 9 SA-CD/CD | SHIFT + 9 Shift + 9 |
| 0/10 0/10 SA-CD/CD | SHIFT + 0 Shift + 0 |
| >10/• -/-- CLEAR -/--/>10 SA-CD/CD | SHIFT + -/-- GUIDE Shift + Guide |
| DISPLAY Display SA-CD/CD | SHIFT + DISPLAY INFO Shift + Info |
| ■ Stop SA-CD/CD | SHIFT + ■ Shift + Stop |
| II Pause | SHIFT + II Shift + Pause |
| ▷ Play SA-CD/CD | SHIFT + PLAY MODE ▶ Shift + Play |
| TUNING – <<< Tuning- | SHIFT + << Shift + << |
| TUNING + >>> Tuning+ | SHIFT + >> Shift + >> |
| TV CH – PRESET – I<<< / Preset - SA-CD/CD | SHIFT + << Shift + I << |
| TV CH + PRESET + >>I / Preset + SA-CD/CD | SHIFT + >>I Shift + >>I |