Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	Play	SLOW	Play / Slow
	[≡]	GOTO TEXT	Text / Goto
	Pause/ [/ ≡]	STEP - FREEZE	Pause / Step / Freeze
	Stop/ [≡+]	HOLD	Stop / Hold
	Rec/ [≡◆]	REC MODE	Rec / Rec Mode
	<<⁄ [≡o]	TUNE-	<< / Tune-
	I <<⁄ [≡i]	PRESET-	I << / Preset-
	>>I / [≡?]	PRESET+	>>I / Preset+
	>>⁄ [≡x]	TUNE+	>> / Tune+
P.MODE	P. Mode	FORMAT PICTURE	Picture / Format
S.MODE	S. Mode	TITLE SOUND	Sound / Title
ANT	ANT	TOP MENU D.MENU	D. Menu / Top
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
1	1	TV 1	1
2	2	DVD 2	2

Original		Replacement	
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
MENU	Menu	HOME MENU	Menu / Home
0	0	HDMI - SAT 0	0
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
BACK/	Back	RETURN BACK	Back / Return
HOME/ SOURCE	Home/ Source	SHIFT + HOME MENU	Shift + Menu / Home

Original		Replacement		Original	Replacement
+	Vol +	VOL +	Vol +		
APPS	APPS	SHIFT + APP REPEAT	Shift + Green / APP /		
P	P+	CH PAGE +	CH+ / Page+		
	Vol -	VOL −	Vol -		
P	P-	CH PAGE −	CH- / Page-		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--		
LIST	List	LIST SMART	Smart / List		
FAV	FAV	PC FAV MARKER	Fav / Marker / PC		